


Quick Installation Guide

Step 5. Install the LED cable (optional)

The ARC-1200 SATA RAID controller provides two kinds of LED status connectors. The Fault/Activity and Global header intelligent electronics logic is as below.



The following position layout is for ARC-1200 Individual LED indicator connector, for each channel and Global LED indicator connector.




Figure 2-4, ARC-1200 global LED connection for Computer Case.

If the system uses only a single global indicator, attach the global indicator cable to the two pins HDD LED connector. Global LED indicator will light up when any drive is active.