

External RAID Cards

ARC-1110MI/1120MI-Multi-lane Connector

(4/8-port PCI-X External SATA II RAID adapters)

ARC-1212x/1222x-Min SAS 4x Connector

(4/8-port PCI-Express External SAS/SATA II RAID adapters)

ARC-1202-eSATA Connector

(2-port PCI-Express External RAID adapter)

USER Manual

Version: 2.0

Issue Date: November, 2009

Microsoft WHQL Windows Hardware Compatibility Test

ARECA is committed to submitting products to the Microsoft Windows Hardware Quality Labs (WHQL), which is required for participation in the Windows Logo Program. Successful passage of the WHQL tests results in both the “Designed for Windows” logo for qualifying ARECA PCI-X and PCI-Express external External RAID adapters and a listing on the Microsoft Hardware Compatibility List (HCL).

Copyright and Trademarks

The information of the products in this manual is subject to change without prior notice and does not represent a commitment on the part of the vendor, who assumes no liability or responsibility for any errors that may appear in this manual. All brands and trademarks are the properties of their respective owners. This manual contains materials protected under International Copyright Conventions. All rights reserved. No part of this manual may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without the written permission of the manufacturer and the author. All inquiries should be addressed to Areca Technology Corporation.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Contents

1. Introduction	10
1.1 Overview	10
1.2 Features	11
2. Hardware Installation	14
2.1 Before Your begin Installation	14
2.2 Board Layout.....	15
2.3 Installation.....	18
2.4 Hot-plug Drive Replacement	27
2.4.1 Recognizing a Drive Failure	27
2.4.2 Replacing a Failed Drive	27
3. McBIOS RAID Manager	30
3.1 Starting the McBIOS RAID Manager	30
3.2 McBIOS RAID manager	31
3.3 Configuring Raid Sets and Volume Sets	32
3.4 Designating Drives as Hot Spares.....	32
3.5 Using Quick Volume/Raid Setup Configuration	33
3.6 Using RAID Set/Volume Set Function Method	34
3.7 Main Menu	36
3.7.1 Quick Volume/RAID Setup	37
3.7.2 Raid Set Function	40
3.7.2.1 Create Raid Set	41
3.7.2.2 Delete Raid Set	42
3.7.2.3 Expand Raid Set.....	43
• Migrating	44
3.7.2.4 Activate Incomplete Raid Set.....	44
3.7.2.5 Create Hot Spare.....	45
3.7.2.6 Delete Hot Spare	46
3.7.2.7 Raid Set Information	46
3.7.3 Volume Set Function	47
3.7.3.1 Create Volume Set.....	47
• Volume Name	49
• Raid Level	49
• Capacity	50
• Stripe Size	52
• SCSI Channel	52
• SCSI ID	53
• Cache Mode	54

• Tag Queuing	54
3.7.3.2 Delete Volume Set	55
3.7.3.3 Modify Volume Set	55
3.7.3.3.1 Volume Growth	56
3.7.3.3.2 Volume Set Migration	57
3.7.3.4 Check Volume Set	57
3.7.3.5 Stop Volume Set Check	58
3.7.3.6 Display Volume Set Info.	58
3.7.4 Physical Drives	59
3.7.4.1 View Drive Information	59
3.7.4.2 Create Pass-Through Disk	60
3.7.4.3 Modify a Pass-Through Disk	60
3.7.4.4 Delete Pass-Through Disk	61
3.7.4.5 Identify Selected Drive	61
3.7.5 Raid System Function	62
3.7.5.1 Mute The Alert Beeper	62
3.7.5.2 Alert Beeper Setting	63
3.7.5.3 Change Password	63
3.7.5.4 JBOD/RAID Function	64
3.7.5.5 Background Task Priority	65
3.7.5.6 Maximum SATA Mode	65
3.7.5.7 HDD Read Ahead Cache	66
3.7.5.8 Volume Data Read Ahead	66
3.7.5.9 Stagger Power On	67
3.7.5.10 Empty HDD slot HDD	68
3.7.5.11 HDD SMART Status Polling	69
3.7.5.12 Controller Fan Detection	69
3.7.5.13 Auto Activate Raid Set	70
3.7.5.14 Disk Write Cache Mode	71
3.7.5.15 Capacity Truncation	71
3.7.6 Ethernet Configuration (ARC-1202)	72
3.7.6.1 DHCP Function	73
3.7.6.2 Local IP address	73
3.7.6.3 Ethernet Address	74
3.7.7 View System Events	75
3.7.8 Clear Events Buffer	75
3.7.9 Hardware Monitor	75
3.7.10 System Information	76

4. Driver Installation 77

4.1 Creating the Driver Diskettes	77
4.2 Driver Installation for Windows	79

4.2.1 New Storage Device Drivers in Windows 2003/Vista/2008/Windows 7.....	79
4.2.2 Install Windows 2000/XP/2003/Vista/2008/Windows 7 on a Adapter Volume.....	79
4.2.3 Installing Adapter into an Existing Windows 2000/XP/2003/Vista/2008/Windows 7 Installation.....	81
4.2.4 Making Volume Sets Available to Windows System.....	82
4.2.5 Uninstall Adapter from Windows 2000/XP/2003/Vista/2008/Windows 7.....	82
4.3 Driver Installation for Linux.....	83
4.4 Driver Installation for FreeBSD.....	84
4.5 Driver Installation for Solaris 10.....	84
4.6 Driver Installation for Mac 10.x.....	84
4.7 Driver Installation for UnixWare 7.1.4.....	85
4.8 Driver Installation for NetWare 6.5.....	85
5. ArcHttp Proxy Server Installation.....	86
5.1 For Windows.....	87
5.2 For Linux.....	88
5.3 For FreeBSD.....	90
5.4 For Solaris 10 x86.....	90
5.5 For Mac OS 10.x.....	91
5.6 ArcHttp Configuration.....	91
6. Web Browser-based Configuration.....	94
6.1 Start-up McRAID Storage Manager.....	94
• Start-up McRAID Storage Manager from Windows Local Administration.....	95
• Start-up McRAID Storage Manager from Linux/FreeBSD/Solaris/Mac Local Administration.....	96
• Start-up McRAID Storage Manager Through Ethernet port (Out-of-Band).....	96
6.2 McRAID Storage Manager.....	97
6.3 Main Menu.....	98
6.4 Quick Function.....	98
6.5 RaidSet Functions.....	99
6.5.1 Create Raid Set.....	99
6.5.2 Delete Raid Set.....	100
6.5.3 Expand Raid Set.....	100
6.5.4 Activate Incomplete Raid Set.....	101
6.5.5 Create Hot Spare.....	102
6.5.6 Delete Hot Spare.....	102
6.5.7 Rescue Raid Set.....	102

6.5.8 Offline Raid Set.....	103
6.6 Volume Set Functions	103
6.6.1 Create Volume Set.....	103
• Volume Name	104
• Raid Level	104
• Capacity	104
• Greater Two TB Volume Support.....	104
• Initialization Mode.....	105
• Stripe Size	105
• Cache Mode	105
• Tag Queuing	106
6.6.2 Delete Volume Set.....	106
6.6.3 Modify Volume Set.....	106
6.6.3.1 Volume Growth	107
6.6.3.2 Volume Set Migration	107
6.6.4 Check Volume Set	108
6.6.5 Stop VolumeSet Check	109
6.7 Physical Drive	109
6.7.1 Create Pass Through Disk.....	109
6.7.2 Modify Pass Through Disk.....	110
6.7.3 Delete Pass Through Disk	110
6.7.4 Identify Selected Drive.....	111
6.8 System Controls	111
6.8.1 System Config	111
• System Beeper Setting	112
• Background Task Priority	112
• JBOD/RAID Configuration	112
• Maximun SATA Supported	112
• HDD Read Ahead Cache	112
• Volume Data Read Ahead	112
• Stagger Power on Control.....	113
• Empty HDD Slot LED	113
• HDD SMART Status Polling.....	113
• Disk Write Cache Mode	114
• Auto Activate Incomplete Raid	114
• Disk Capacity Truncation Mode.....	114
6.8.2 Ethernet Configuration (ARC-1202).....	115
6.8.3 Alert by Mail Configuration (ARC-1202)	116
6.8.4 SNMP Configuration (ARC-1202).....	116
• SNMP Trap Configurations	117
• SNMP System Configurations	117
• SNMP Trap Notification Configurations.....	117

6.8.5 NTP Configuration (ARC-1202)	117
• NTP Sever Address	118
• Time Zone.....	118
• Automatic Daylight Saving.....	118
6.8.6 View Events/Mute Beeper	119
6.8.7 Generate Test Event	119
6.8.8 Clear Events Buffer.....	120
6.8.9 Modify Password	120
6.8.10 Update Firmware	121
6.9 Information.....	121
6.9.1 RaidSet Hierarchy.....	121
6.9.2 System Information.....	122
6.9.3 Hardware Monitor.....	122
Appendix A	124
Upgrading Flash ROM Update Process.....	124
Upgrading Firmware Through McRAID Storage Manager	124
Upgrading Firmware Through nflash DOS Utility	126
Appendix B.....	128
Battery Backup Module (ARC6120-BAT-xxx)	128
BBM Components	128
Status of BBM	128
Installation	128
Battery Backup Capacity.....	129
Operation	129
Changing the Battery Backup Module	129
BBM Specifications.....	130
Appendix C.....	131
SNMP Operation & Definition	131
Appendix D.....	138
Event Notification Configurations	138
A. Device Event.....	138
B. Volume Event.....	139
C. RAID Set Event	140
D. Hardware Monitor Event	140
Appendix E	142
RAID Concept	142
RAID Set.....	142
Volume Set.....	142
Ease of Use Features.....	143
• Foreground Availability/Background Initialization	143
• Online Array Roaming	143

• Online Capacity Expansion.....	143
• Online RAID Level and Stripe Size Migration	145
• Online Volume Expansion	146
High availability.....	146
• Global Hot Spares	146
• Hot-Swap Disk Drive Support	147
• Auto Declare Hot-Spare	147
• Auto Rebuilding	148
• Adjustable Rebuild Priority	148
High Reliability	149
• Hard Drive Failure Prediction	149
• Auto Reassign Sector.....	149
• Consistency Check	150
Data Protection	150
• Battery Backup	150
• Recovery ROM	151
Appendix F	151
Understanding RAID	151
• RAID 0	152
• RAID 1	152
• RAID 10	153
• RAID 3	153
• RAID 5	154
• RAID 6	155
• JBOD	155
• Single Disk (Pass Through Disk).....	155
Appendix H.....	158
Technical Support	158

INTRODUCTION

1. Introduction

This section presents a brief overview of the external SATA RAID adapter series, 1110MI/1120MI (4/8-port PCI-X), 1212x/1222x (4/8-port PCIe x8) and ARC-1202 (2-port PCIe x1) external RAID adapter for your PC and server systems.

1.1 Overview

Areca external RAID adapters support 4/8 SATA II or SAS/SATA peripheral devices on a single host adapter. These external RAID adapters have the same RAID kernel of its field-proven external RAID controllers. External enclosure benefits all functions from these adapters.

Unparalleled Performance

The external RAID adapters raise the standard to higher performance levels with several enhancements including Intel high-performance I/O Processor, a new memory architecture and high performance PCI-X/Express bus interconnection. The ARC-11x0MI default supports 256MB on-board ECC DDR333 SDRAM memory. The ARC-12x2x default supports 512MB on board ECC DDR-533 SDRAM memory. The ARC-1202 default supports 128MB on board DDR2-400 SDRAM memory.

Unsurpassed Data Availability

The RAID 6 can offer fault tolerance greater than RAID 1 or RAID 5 but only consumes the capacity of 2 disk drives for distributed parity data. The external RAID adapters with extreme performance RAID 6 engine supported provide the highest RAID 6 feature to meet this requirement. The adapter can concurrently compute two parity blocks and get comparable with RAID 5 performance.

The external RAID adapters can also provide RAID levels 0, 1, 10, 3, 5, 6, Single Disk and JBOD RAID for maximum configuration flexibility. Its high data availability and protection derives from the following capabilities: Online RAID Capacity Expansion, Array Roaming, Online RAID Level/Stripe Size Migration, Global Online

INTRODUCTION

Spare, Automatic Drive Failure Detection, Automatic Failed Drive Rebuilding, Disk Hot-Swap, Online Background Rebuilding, Instant Availability/ Background Initialization, Auto Reassign sector, and Battery Backup.

With Redundant Flash image feature, the controller will revert back to the last known version of firmware and continue operating. This reduces the risk of system failure due to firmware crash. Greater than Two TB support allows for very large volume set application in 64-bit environment such as data-mining and managing large databases.

Easy RAID Management

The adapter firmware contains a browser-based McRAID storage manager that can access through the Http Proxy server in Mac OS X environment. The McRAID storage manager allows local and remote to create and modify RAID set, volume set, and monitor RAID status from standard web browser. API software components and CLI also support for the RAID manager. Enclosure management features include fault indicators and status LED via serial bus cable.

1.2 Features

Adapter Architecture

- Intel IOP 331 I/O processor (ARC-1110MI/1120MI)
- Intel 1200MHz IOP 348 I/O processor (ARC-1212x/1222x)
- ARM 400 MHz I/O processor (ARC-1202)
- 64-bit/133MHz PCI-X Bus compatible (ARC-1110MI/1120MI)
- PCI Express X8 compatible (12x2x)
- PCI Express X1 compatible (ARC-1202)
- 256MB on-board DDR-333 memory with ECC protection
- 512MB on-board DDR2-533 memory with ECC protection
- 128MB on-board SDRAM (ARC-1202)
- Support up to 4/8 SATA II or SAS/SATA II drives
- Write-through or write-back cache support
- Multi-adapter support for large storage requirements
- Supports extreme performance Intel RAID 6 functionality
- NVRAM for RAID event & transaction log
- Battery backup module (BBM) ready

INTRODUCTION

RAID Features

- RAID level 0, 1, 10, 3, 5, 6, Single Disk and JBOD
- Multiple RAID selection
- Online Array roaming
- Offline RAID set
- Online RAID level/stripe size migration
- Online capacity expansion & RAID level migration simultaneously
- Online volume set growth
- Instant availability and background initialization
- Automatic drive insertion / removal detection and rebuilding
- Greater than 2TB per volume set for 64-bit LBA
- Redundant flash image for adapter availability
- Support SMART, NCQ and OOB staggered spin-up capable drives

Monitors/Notification

- System status indication through LED/LCD connector and alarm buzzer
- SMTP support for email notification
- SNMP trap supports for remote SNMP Manager
- Serial bus Enclosure Management Ready
- In-Band Enclosure Management Ready (ARC-1202)

RAID Management

- Field-upgradeable firmware in flash ROM
- Ethernet port support (ARC-1202)

In-Band Manager

- Hot key boot-up McBIOS RAID manager via M/B BIOS
- Support controller's API library, allowing customer to write its own AP
- Support Command Line Interface (CLI)
- Browser-based management utility via ArchHttp proxy server
- Single Admin Portal (SAP) monitor utility
- Disk Stress Test (DST) utility for production in Windows

Out-of-Band Manager

- Firmware-embedded browser-based MCRAID storage manager, SMTP manager, SNMP agent and Telnet function via Ethernet port (ARC-1202)

INTRODUCTION

- Support controller's API library for customer to write its own AP (ARC-1202)
- Push Button and LCD display panel (option)

Operating System

- Windows 2000/XP/Server 2003/Vista/2008/Windows 7
- Red Hat Linux
- SuSE Linux
- FreeBSD
- Novell Netware 6.5
- Solaris 10 X86/X86_64
- SCO Unixware 7.1.4
- Mac OS X 10.x (EFI BIOS support)

(For latest supported OS listing visit <http://www.areca.com.tw>)

PCI-X RAID Adapters Comparison (ARC-11x0MI)		
	1110MI	1120MI
RAID processor	IOP331	
Host Bus Type	PCI-X 64bit/133MHz	
RAID 6 support	Yes	Yes
Cache Memory	256MB	256MB
Drive Support	4 x SATA II	8 x SATA II
Disk Connector	1 x External SFF-8470	2 x External SFF-8470

PCI-Express RAID Adapters Comparison (ARC-12x2x/1202)			
	1212x	1222x	1202
RAID Processor	IOP348	IOP348	ARM
Host Bus Type	PCI-Express x8		PCI-Express x1
RAID Level	0, 1, 10, 3, 5, 6, Single Disk or JBOD	0, 1, 10, 3, 5, 6, 30, 50, 60, Single Disk or JBOD	0, 1, 10, 3, 5, 6, Single Disk or JBOD
Cache Memory	512MB	512MB	128MB
Drive Support	4 x SAS/SATA II	8 x SAS/SATA II	Up to 8 (Port Multiplier)
Disk Connector	SFF-8088	2 x SFF-8088	2 x eSATA
BBM	Yes	Yes	N/A

HARDWARE INSTALLATION

2. Hardware Installation

This section describes the procedures for installing the external RAID adapters.

2.1 Before You Begin Installing

Thanks for purchasing the external RAID adapters as your RAID data storage and management system. This user guide gives simple step-by-step instructions for installing and configuring the external RAID adapters. To ensure personal safety and to protect your equipment and data, carefully read the information following the package content list before you begin installing.

Package Contents

If any items listed in your package is missing, please contact your local dealer before proceeding with installation **(disk drives and disk mounting brackets are not included)**:

ARC-11x0MI/12x2x/1202 series external RAID adapters

- 1 x PCI-X/PCIe external RAID adapter in an ESD-protective bag
- 1 x Installation CD
- 1 x User Manual

HARDWARE INSTALLATION

2.2 Board Layout

Follow the instructions below to install a external RAID adapter into your PC/Server.




Figure 2-1, ARC-1110MI/1120MI (4/8-port PCI-X External RAID adapters)




Figure 2-2, ARC-1212x/1222x (4/8-port PCI Express External SAS/SATA II RAID adapters)

HARDWARE INSTALLATION




Figure 2-3, ARC-1202 (2-port PCI-Express External RAID adapter)

Tools Required

An ESD grounding strap or mat is required. Also required are standard hand tools to open your system's case.

System Requirement

The external RAID adapter can be installed in a universal PCI and requires a motherboard that:

ARC-11x0MI series required one of the following:

- PCI-X 64-bit 66/100/133 MHz, 3.3V.

ARC-12x2x series requires:

- PCI-Express x8

It can work on the PCIe x1, x4 and x8 signal on x8 or x16 slot M/B.

ARC-1202 requires:

- PCI-Express x1

HARDWARE INSTALLATION

The external RAID adapter may be connected to up to 4/8 SATA or 4/8 SAS/SATA II hard drives using the supplied cables. Optional serial bus cable is required to connect drive activity/fault LEDs on the enclosure to the external RAID adapter.

Installation Tools

The following items may be needed to assist with installing the external RAID adapter into an available PCI expansion slot.

- Small screwdriver
- Host system hardware manuals and manuals for the disk or enclosure being installed.

Personal Safety Information

To ensure personal safety as well as the safety of the equipment:

- Always wear a grounding strap or work on an ESD-protective mat.
- Before opening the system cabinet, turn off power switches and unplug the power cords. Do not reconnect the power cords until you have replaced the covers.

Warning:

High voltages may be found inside computer equipment. Before installing any of the hardware in this package or removing the protective covers of any computer equipment, turn off power switches and disconnect power cords. Do not reconnect the power cords until you have replaced the covers.

Electrostatic Discharge

Static electricity can cause serious damage to the electronic components on this external RAID adapter. To avoid damage caused by electrostatic discharge, observe the following precautions:

- Do not remove the external RAID adapter from its anti-static packaging until you are ready to install it into a computer case.

HARDWARE INSTALLATION

- Handle the external RAID adapter by its edges or by the metal mounting brackets at its each end.
- Before you handle the external RAID adapter in any way, touch a grounded, anti-static surface, such as an unpainted portion of the system chassis, for a few seconds to discharge any built-up static electricity.

2.3 Installation

Follow the instructions below to install an external RAID adapter into your PC/Server.

Step 1. Unpack

Unpack and remove the external RAID adapter from the package. Inspect it carefully, if anything is missing or damaged, contact your local dealer.

Step 2. Shut Down PC/Server

Turn off computer and remove the AC power cord. Remove the system's cover. See the computer system documentation for instruction.

Step 3. Install the External RAID Adapters

To install the external RAID adapter remove the mounting screw and existing bracket from the rear panel behind the selected PCI slot. Align the gold-fingered edge on the card with the selected PCI expansion slot. Press down gently but firmly to ensure that the card is properly seated in the slot, as shown in Figure 2-4. Then, screw the bracket into the computer chassis. ARC-11x0MI adapters can fit in PCI-X slots. ARC-12x2x adapters require a PCI-Express x8 slot. ARC-1202 adapter can work on the PCIe x1, x4, x8, and x16 slot.

HARDWARE INSTALLATION




Figure 2-4, Insert External RAID Adapter into a PCI-X slot

Step 4. Install the Drives in the ARC-4020/4020MI RAID Box

1. Gently slide the drive tray out from the ARC-4020/4020MI RAID box.
2. Install the drive into the drive tray and secure the drive to the drive tray by four of the mounting screws.
3. After all drives are in the drive tray, slide all of them back into the ARC-4020/4020MI RAID box and make sure you latch the drive trays.




Figure 2-5, Secure the Drive to the Drive Tray

HARDWARE INSTALLATION

Step 5. Connect the External Box Cable

The ARC-4020/4020MI is an external solution with Port Multiplier (PM) and Multi-lane (MI) host connectivity for use with your PC or Mac workstation. A Port Multiplier is a mechanism for one active host connection to communicate with multiple devices. The ARC-4020 enclosure contains one 1-to-4 Port Multiplier which is used to create four SATA connections inside.




Figure 2-6, eSATA Cable Connected Between ARC-1202 Adapter & External ARC-4020 Box

Model ARC-1110MI/1120MI have External Multilane connectors (SFF-8470), each of them can support up to four SATA drives.





Figure 2-7, External Multilane to Multilane Cable (SFF-8470 to SFF-8470)

HARDWARE INSTALLATION

Model ARC-1211x/1221x have Min SAS 4x (SFF-8088) connectors, each of them can support up to four SAS/SATA drives.

Figure 2-8, External Min SAS 4x to Multilane Cable (SFF-8088 to SFF-8470)



Those boards can utilize the external SFF-8470 to SFF-8470 or SFF-8088 to SFF-8470 cable outside the PC or Mac to bring the internal SATA interface to out of the box.





Figure 2-9, Connector Connected Between External RAID Adapter & External ARC-4020MI Box

Step 6. Install the External Serial Bus LED Cable (optional)

You also can connect the serial bus interface to a proprietary SATA backplane enclosure. This signal provide the drive status information including activity/fault LED.

The following is the serial bus signal name description for LCD & fault/activity LED.

HARDWARE INSTALLATION



PIN	Description	PIN	Description
2	Power (+5V) 2 GND	4	LCD Module Interrupt 4 Fault/Activity Interrupt
6	LCD Module Serial Data 6 Fault/Activity clock	8	Fault/Activity Serial Data 8 LCD Module clock

You can connect the serial bus to the ARC-4020MI serial bus input connector (SI, RJ11) and cascade its serial bus output connector (SO, RS232), then connect to the other ARC-4020MI serial bus input connector (SI, RJ11), as shown below.




Figure 2-10, Serial Bus Cable Connected Between External RAID Adapter & External ARC-4020MI Box

HARDWARE INSTALLATION

The following describes the fault/activity LED and power/global fault location and function.




Figure 2-11, Activity/Fault LED and Power LED for External ARC-4020MI and ARC-4020 Box

LED	Normal Status	Problem Indication
1. Activity LED	When the activity LED is illuminated, there is I/O activity on that disk drive. When the LED is dark; there is no activity on that disk drive.	N/A
2. Fault LED	When the fault LED is solid illuminated, there is no disk present.	When the fault LED is off, that disk is present and status is normal. When the fault LED is slow blinking (2 times/sec), that disk drive has failed and should be hot-swapped immediately. When the activity LED is illuminated and fault LED is fast blinking (10 times/sec) there is rebuilding activity on that disk drive.
3. Power LED	When the power LED is solid illuminated, the enclosure is on the power on stage.	N/A

HARDWARE INSTALLATION

Step 7. Re-check the HDD LED and Fault LED Signal Connections

Be sure that the proper failed drive channel information is displayed by the fault and HDD activity LEDs. An improper signal connection will tell the user to “Hot Swap” the wrong drive. This will remove the wrong disk (one that is functioning properly) from the adapter. This can result in failure and loss of system data.

Step 8. Power up the System

Check the installation thoroughly, reinstall the computer cover, and reconnect the power cord cables. Turn on the power switch at the rear of the computer (if equipped) and then press the power button at the front of the host computer.

Step 9. Configure Volume Set

For PC system:

- The external RAID adapter configures RAID functionality through the McBIOS RAID manager. Please refer to Chapter 3, McBIOS RAID manager, for the detail regarding configuration. The external RAID adapter can also be configured through the McRAID storage manager software utility with ArchHttp proxy server installed through on-board LAN port or LCD module. For this option, please refer to Chapter 6, Web Browser-Based Configuration or LCD Configuration Menu.

For Mac system:

- The EFI-enabled products do not include the EFI shell binary, you can only create the RAID configuration through the McRAID storage manager with driver and Archhttp proxy server installed. For this option, please refer to Chapter 6, Web Browser-Based Configuration.

Step 10. Install the Adapter Driver

After hardware installation, the disk drives connected to the external RAID adapter must be configured and the volume set units initialized by the controller before they are ready to use by the system.

HARDWARE INSTALLATION

You must have administrative level permissions to install external RAID adapter driver & software. You can install driver & software on your PC/server system as below:

For a new system:

- Driver installation usually takes places as part of operating system installation. Please refer to Chapter 4, Diver Installation for the detail installation procedure.

In an existing system:

- Install the controller driver into the existing operating system. Please refer to the Chapter 4, Driver Installation for the detailed installation procedure.

Note:

- 1.The Mac OS X 10.5.x and 10.6.x has included the driver for Areca Intel IOP(331/333/348) based SATA and SAS RAID adapters. You can directly install the Mac OS X 10.5.x and 10.6.x to Areca Intel IOP based volume set without using the Ghost utility.
2. For latest release versions of drivers, please download from <http://www.areca.com.tw>

Step 11. Install ArchHttp Proxy Server

The external RAID adapter firmware has embedded the web-browser McRAID storage manager. ArchHttp proxy server will enable it. The browser-based McRAID storage manager provides all of the creation, management, and monitor external RAID adapter status. Please refer to the Chapter 5 for the detail ArchHttp Proxy Server Installation. For SNMP agent function, please refer to Appendix C.

Step 12. Determining the Boot Sequences

For PC system:

- The external RAID adapter is a bootable adapter. If your system already contains a bootable device with an installed operating system, you can set up your system to boot a second operating system from the new adapter. To add a second bootable adapter,

HARDWARE INSTALLATION

you may need to enter setup of M/B BIOS and change the device boot sequence so that the external RAID adapter heads the list. If the system BIOS setup does not allow itself to act as a second boot device, change, your system may not be configurable to allow the external RAID adapter to act as a second boot device.

For Mac Pro system:

- The currently Mac OS X 10.4.7, 10.5.x and 10.6.x can not directly boot up from Areca adapter's volume (We do not support the Open Firmware) on the Power Mac G5 machine and can only use as a secondary storage. All Intel based Mac Pro machines use EFI to boot (not Open Firmware, which was used for PPC Macs) the system. Areca has supported the EFI BIOS on its external RAID adapter. You have other alternatively to add Areca volume set on the Mac Pro bootable device listing. You can follow the following procedures to add Areca PCIe RAID adapter on the Mac Pro bootable device listing.

- (1). Upgrade the EFI BIOS from shipping <CD-ROM>\Firmware\Mac\ directory or from the www.areca.com.tw, if the adapters default ship with a legacy BIOS for the PC. Please follow the Appendix A Upgrading Flash ROM Update Process to update the legacy BIOS to EFI BIOS for Mac Pro to boot up from Areca adapter's volume.

- (2). Ghost (such as Carbon Copy Cloner ghost utility) the Mac OS X 10.4.x, 10.5.x or 10.6.x system disk on the Mac Pro to the Areca external RAID adapter volume set. Carbon Copy Cloner is an archival type of back up software. You can take your whole Mac OS X system and make a carbon copy or clone to Areca volume set like an other hard drive. You can also directly install the Mac OS X 10.5.x and 10.6.x to Areca Intel IOP Based volume set without using the Ghost utility.

- (3). Power up the Mac Pro machine, it will take about 30 seconds for adapter firmware ready. This periodic will let the boot up screen blank before Areca volume in the bootable device list.

2.4 Hot-plug Drive Replacement

The external RAID adapter supports the ability of performing a hot-swap drive replacement without powering down the system. A disk can be disconnected, removed, or replaced with a different disk without taking the system off-line. The RAID rebuilding will be processed automatically in the background. When a disk is hot swap, the external RAID adapter may no longer be fault tolerant. Fault tolerance will be lost until the hot swap drive is subsequently replaced and the rebuild operation is completed.

2.4.1 Recognizing a Drive Failure

A drive failure can be identified in one of the following ways:

1. An error status message lists failed drives in the event log.
2. A fault LED illuminates on the front of RAID subsystem if failed drives are inside.

2.4.2 Replacing a Failed Drive

With RAID adapter drive tray, you can replace a defective physical drive while your computer is still operating. When a new drive has been installed, data reconstruction will be automatically started to rebuild the contents of the disk drive.

Note:

The capacity of the replacement drives must be at least as large as the capacity of the other drives in the raid set. Drives of insufficient capacity will be failed immediately by the RAID adapter without starting the Automatic Data Re-build.


HARDWARE INSTALLATION

Summary of the Installation

The flow chart below describes the installation procedures for external RAID adapter. These procedures include hardware installation, the creation and configuration of a RAID volume through the McBIOS/McRAID, OS installation and installation of external RAID adapter software.

The software components configure and monitor the external RAID adapter via ArchHttp proxy server.

Configuration Utility	Operating System Supported
McBIOS RAID Manager	OS-Independent
McRAID Storage Manager (Via Archhttp proxy server)	Windows 2000/XP/2003/Vista/2008, Linux, FreeBSD, Solaris and Mac/ Windows 7
SAP Monitor (Single Admin Portal to scan for multiple RAID units in the network, Via ArchHttp proxy server)	Windows 2000/XP/2003/Vista/2008/ Windows 7
SNMP Manager Console Integration	Windows 2000/XP/2003/Vista/2008/ Window 7, Linux, FreeBSD



McRAID Storage Manager

Before launching the firmware-embedded web server, McRAID storage manager, you can to install the ArchHttp proxy server on your server system or through on-board LAN-port (if equipped). If you need additional information about installation and start-up of this function, see the McRAID Storage Manager section in Chapter 6.

SNMP Manager Console Integration

● Out of Band-Using Ethernet Port (ARC-1202)

Before launching the firmware-embedded SNMP agent in the sever, you need first to enable the fireware-embedded SNMP agent function on your external RAID adapter. If you need additional information about installation and start-up this function, see the section 6.8.4 SNMP Configuration.

● In-Band-Using PCI-X/PCIe Bus

Before launching the SNMP agent in the sever, you need to enable the fireware-embedded SNMP community configuration first and install Areca SNMP extension agent in your server system. If you need additional information about installation and start-up the function, see the SNMP Operation & Installation section in the Appendix C.

Single Admin Portal (SAP) Monitor

This utility can scan for multiple RAID units on the network and monitor the controller set status. It also includes a disk stress test utility to identify marginal spec disks before putting the RAID unit into a production environment.

For additional information, see the utility manual in the packaged software CD or download it from the web site <http://www.areca.com.tw>

BIOS CONFIGURATION

3. McBIOS RAID Manager

The system mainboard BIOS automatically configures the following External RAID adapter parameters at power-up:


- I/O Port Address
- Interrupt Channel (IRQ)
- Adapter ROM Base Address

Use McBIOS RAID manager to further configure the external RAID adapter to suit your server hardware and operating system.

3.1 Starting the McBIOS RAID Manager

This section explains how to use the McBIOS RAID manager to configure your RAID system. The McBIOS RAID manager is designed to be user-friendly. It is a menu-driven program, residing in the firmware, which allows you to scroll through various menus and sub-menus and select among the predetermined configuration options.

When starting a system with an external RAID adapter installed, it will display the following message on the monitor during the start-up sequence (after the system bios startup screen but before the operating system boots):




```
ARC-1xxx RAID Ctrl - DRAM: 128(MB) / #Channels: 8
BIOS: V1.00 / Date: 2004-5-13 - F/W: V1.31 / Date: 2004-5-31
▶ I/O-Port=F3000000h, IRQ=11, BIOS ROM mapped at D000:0h
▶▶ No BIOS disk Found, RAID Controller BIOS not installed!
▶▶ Press <Tab/F6> to enter SETUP menu. 9 second(s) left <ESC to Skip>..
```


The McBIOS RAID manager message remains on your screen for about nine seconds, giving you time to start the configuration menu by pressing **Tab** or **F6**. If you do not wish to enter configuration menu, press **ESC** to skip configuration immediately. When activated, the McBIOS RAID manager appears showing a selection dialog box listing the external RAID adapter that are installed in the system.

The legend at the bottom of the screen shows you what keys are enabled for the screens.

BIOS CONFIGURATION



Use the **Up** and **Down** arrow keys to select the adapter you want to configure. While the desired adapter is highlighted, press the **Enter** key to enter the main menu of the McBIOS RAID manager.



Note:

The manufacture default password is set to **0000**; this password can be modified by selecting **Change Password** in the **Raid System Function** section.

3.2 McBIOS RAID manager

The McBIOS RAID manager is firmware-based and is used to configure RAID sets and volume sets. Because the utility resides in the external RAID adapter firmware, operation is independent of any operating systems on your computer. This utility can be used to:

- Create RAID sets,
- Expand RAID sets,
- Add physical drives,
- Define volume sets,

BIOS CONFIGURATION

- Modify volume sets,
- Modify RAID level/stripe size,
- Define pass-through disk drives,
- Modify system functions, and
- Designate drives as hot spares.

3.3 Configuring Raid Sets and Volume Sets

You can configure RAID sets and volume sets with McBIOS RAID manager automatically using “Quick Volume/Raid Setup” or manually using “Raid Set/Volume Set Function”. Each configuration method requires a different level of user input. The general flow of operations for RAID set and volume set configuration is:

Step	Action
1	Designate hot spares/pass-through drives (optional).
2	Choose a configuration method.
3	Create RAID sets using the available physical drives.
4	Define volume sets using the space available in the RAID Set.
5	Initialize the volume sets and use volume sets (as logical drives) in the host OS.

3.4 Designating Drives as Hot Spares

Any unused disk drive that is not part of a RAID set can be designated as a hot spare. The “Quick Volume/Raid Setup” configuration will add the spare disk drive and automatically display the appropriate RAID level from which the user can select. For the “Raid Set Function” configuration option, the user can use the “Create Hot Spare” option to define the hot spare disk drive.

When a hot spare disk drive is being created using the “Create Hot Spare” option (in the “Raid Set Function”), all unused physical devices connected to the current controller appear:

Choose the target disk by selecting the appropriate check box. Press the **Enter** key to select a disk drive, and press **Yes** in the create hot spare to designate it as a hot spare.

BIOS CONFIGURATION

3.5 Using Quick Volume/Raid Setup Configuration

“Quick Volume/Raid Setup” configuration collects all available drives and includes them in a RAID set. The RAID set you create is associated with exactly one volume set. You will only be able to modify the default RAID level, the stripe size, and the capacity of the new volume set. Designating drives as hot spares is also possible in the RAID level selection option. The volume set default settings will be:

Parameter	Setting
Volume Name	Volume Set # 00
SCSI Channel/SCSI ID/SCSI LUN	0/0/0
Cache Mode	Write Back
Tag Queuing	Yes

The default setting values can be changed after configuration is completed. Follow the steps below to create arrays using the “Quick Volume/ Raid Setup” method:

Step	Action
1	Choose “Quick Volume/Raid Setup” from the main menu. The available RAID levels with hot spare for the current volume set drive are displayed.
2	<p>It is recommended that you use drives of the same capacity in a specific array. If you use drives with different capacities in an array, all drives in the RAID set will be set to the capacity of the smallest drive in the RAID set.</p> <p>The numbers of physical drives in a specific array determines which RAID levels that can be implemented in the array.</p> <p>RAID 0 requires 1 or more physical drives.</p> <p>RAID 1 requires at least 2 physical drives.</p> <p>RAID 1+Spare requires at least 3 physical drives.</p> <p>RAID 10 requires at least 4 physical drives.</p> <p>RAID 3 requires at least 3 physical drives.</p> <p>RAID 5 requires at least 3 physical drives.</p> <p>RAID 3 +Spare requires at least 4 physical drives.</p> <p>RAID 5 + Spare requires at least 4 physical drives.</p> <p>RAID 6 requires at least 4 physical drives.</p> <p>RAID 6 + Spare requires at least 5 physical drives.</p> <p>Highlight the desired RAID level for the volume set and press the Enter key to confirm.</p>

BIOS CONFIGURATION

3	The capacity for the current volume set is entered after highlighting the desired RAID level and pressing the Enter key. The capacity for the current volume set is displayed. Use the UP and DOWN arrow keys to set the capacity of the volume set and press the Enter key to confirm. The available stripe sizes for the current volume set are then displayed.
4	Use the UP and DOWN arrow keys to select the current volume set stripe size and press the Enter key to confirm. This parameter specifies the size of the stripes written to each disk in a RAID 0, 1, 10, 5 or 6 volume set. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB. A larger stripe size provides better read performance, especially when the computer performs mostly sequential reads. However, if the computer performs random read requests more often, choose a smaller stripe size.
5	When you are finished defining the volume set, press the Enter key to confirm the "Quick Volume/Raid Setup" function.
6	Foreground (Fast Completion) Press Enter key to define Foreground Initialization or Selected the Background (Instant Available) or No Init. In the Background Initialization, the initialization proceeds as a background task, the volume set is fully accessible for system reads and writes. The operating system can instantly access to the newly created arrays without requiring a reboot and waiting the initialization complete. In Foreground Initialization, the initialization proceeds must be completed before the volume set ready for system accesses. In No Init, there is no initialization on this volume.
7	Initialize the volume set you have just configured.
8	If you need to add additional volume set, using main menu "Create Volume Set" function.

3.6 Using RAID Set/Volume Set Function Method

In "Raid Set Function", you can use the "Create Raid Set Function" to generate a new RAID set. In "Volume Set Function", you can use the "Create Volume Set" function to generate an associated volume set and and configuration parameters.

If the current adapter has unused physical devices connected, you can choose the "Create Hot Spare" option in the "Raid Set Function" to define a global hot spare. Select this method to configure new RAID sets and volume sets. The "Raid Set/Volume Set Function" configuration option allows you to associate volume sets with partial and full RAID sets.

BIOS CONFIGURATION

Step	Action
1	To setup the hot spare (option), choose "Raid Set Function" from the main menu. Select the "Create Hot Spare" and press the Enter key to define the hot spare.
2	Choose "RAID Set Function" from the main menu. Select "Create Raid Set" and press the Enter key.
3	The "Select a Drive For Raid Set" window is displayed showing the SATA drives connected to the External RAID adapter.
4	<p>Press the UP and DOWN arrow keys to select specific physical drives. Press the Enter key to associate the selected physical drive with the current RAID set.</p> <p>It is recommended that you drives of the same capacity in a specific array. If you use drives with different capacities in an array, all drives in the RAID set will be set to the capacity of the smallest drive in the RAID set. The numbers of physical drives in a specific array determines which RAID levels that can be implemented in the array.</p> <p>RAID 0 requires 1 or more physical drives. RAID 1 requires at least 2 physical drives. RAID 10 requires at least 4 physical drives. RAID 3 requires at least 3 physical drives. RAID 5 requires at least 3 physical drives. RAID 6 requires at least 4 physical drives.</p>
5	After adding the desired physical drives to the current RAID set, press Yes to confirm the "Create Raid Set" function.
6	An "Edit The Raid Set Name" dialog box appears. Enter 1 to 15 alphanumeric characters to define a unique identifier for this new raid set. The default raid set name will always appear as Raid Set. #. Press Enter to finish the name editing.
7	Press the Enter key when you are finished creating the current RAID set. To continue defining another RAID set, repeat step 3. To begin volume set configuration, go to step 8.
8	Choose the "Volume Set Function" from the main menu. Select "Create Volume Set" and press the Enter key.
9	Choose a RAID set from the "Create Volume From Raid Set" window. Press the Enter key to confirm the selection.
10	Choosing Foreground (Fast Completion) or Background (Instant Availability) initialization or No Init (To Rescue Volume): during Background Initialization, the initialization proceeds as a background task and the volume set is fully accessible for system reads and writes. The operating system can instantly access the newly created arrays without requiring a reboot and waiting for initialization complete. In Foreground Initialization, the initialization must be completed before the volume set is ready for system accesses. In Fast Initialization, initiation is completed more quickly but volume access by the operating system is delayed. When No Init, there is no initialization on this volume.

BIOS CONFIGURATION


- 11 If space remains in the raid set, the next volume set can be configured. Repeat steps 8 to 10 to configure another volume set.

Note:

The “Modify Volume Set” method provides the same functions as the “Create Volume Set” configuration method. In the “Volume Set function”, you can use “Modify Volume Set” to change all volume set parameters except for capacity (size).

3.7 Main Menu

The main menu shows all functions that are available for executing actions, which is accomplished by clicking on the appropriate link.



Note:

The manufacture default password is set to **0000**; this password can be modified by selecting **Change Password** in the **Raid System Function** section.

Option	Description
Quick Volume/Raid Setup	Create a default configuration based on the number of physical disk installed
Raid Set Function	Create a customized RAID set
Volume Set Function	Create a customized volume set
Physical Drives	View individual disk information
Raid System Function	Setup the RAID system configuration
Ethernet Configuration	Ethernet LAN setting (ARC-1202)
View System Events	Record all system events in the buffer
Clear Event Buffer	Clear all information in the event buffer
Hardware Monitor	Show the hardware system environment status
System Information	View the controller system information

BIOS CONFIGURATION


This password option allows user to set or clear the external RAID adapter's password protection feature. Once the password has been set, the user can only monitor and configure the raid controller by providing the correct password. The password is used to protect the external RAID adapter from unauthorized entry. The adapter will only prompt for the password when entering the main menu from the initial screen. The external RAID adapter will automatically return to the initial screen when it does not receive any command in twenty seconds.

3.7.1 Quick Volume/RAID Setup

"Quick Volume/RAID Setup" is the fastest way to prepare a RAID set and volume set. It requires only a few keystrokes to complete. Although disk drives of different capacity may be used in the RAID set, it will use the capacity of the smallest disk drive as the capacity of all disk drives in the RAID set. The "Quick Volume/RAID Setup" option creates a RAID set with the following properties:

1. All of the physical drives are contained in one RAID set.
2. The RAID level, hot spare, capacity, and stripe size options are selected during the configuration process.
3. When a single volume set is created, it can consume all or a portion of the available disk capacity in this RAID set.
4. If you need to add an additional volume set, use the main menu "Create Volume Set" function.


The total number of physical drives in a specific RAID set determine the RAID levels that can be implemented within the RAID



BIOS CONFIGURATION

Set. Select "Quick Volume/RAID Setup" from the main menu; all possible RAID level will be displayed on the screen.

If volume capacity will exceed 2TB, controller will show the "Greater Two TB Volume Support" sub-menu.



- **No**

It keeps the volume size with max. 2TB limitation.

- **LBA 64**

This option use 16 bytes CDB instead of 10 bytes. The maximum volume capacity supports up to 512TB.

This option works on different OS which supports 16 bytes CDB. Such as:

Windows 2003 with SP1

Linux kernel 2.6.x or latter

- **For Windows**


It change the sector size from default 512 Bytes to 4k Bytes. the maximum volume capacity up to 16TB.

This option works under Windows platform only. And it can not be converted to "Dynamic Disk", because 4k sector size is not a standard format.


For more details please download PDF file from **ftp://ftp.areca.com.tw/RaidCards/Documents/Manual_Spec/Over2TB_050721.zip**

BIOS CONFIGURATION

A single volume set is created and consumes all or a portion of the disk capacity available in this RAID set. Define the capacity of volume set in the "Available Capacity" popup. The default value for the volume set, which is 100% of the available capacity, is displayed in the selected capacity. Use the **UP** and **DOWN** keys to select the capacity, press the **Enter** key to accept this value. If the volume set uses only part of the RAID set capacity, you can use the "Create Volume Set" option in the main menu to define additional volume sets.




Stripe Size This parameter sets the size of the stripe written to each disk in a RAID 0, 1, 10, 5, or 6 logical drive. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB. A larger stripe size produces better-read performance, especially if your computer does mostly sequential reads. However, if you




BIOS CONFIGURATION

are certain that your computer performs random reads more often, select a smaller stripe size. Press the **Yes** option in the “Create Vol/Raid Set” dialog box, the RAID set and volume set will start to initialize it.




Select “Foreground (Faster Completion)” or “Background (Instant Available)” for initialization. “No Init (To Rescue Volume)” for recovering the missing RAID set configuration



3.7.2 Raid Set Function

Manual configuration gives complete control of the RAID set setting, but it will take longer to configure than “Quick Volume/Raid Setup” configuration. Select “Raid Set Function” to manually configure the RAID set for the first time or delete existing RAID sets and reconfigure the RAID set.

BIOS CONFIGURATION




3.7.2.1 Create Raid Set

To define a RAID set, follow the procedure below:


1. Select "Raid Set Function" from the main menu.
2. Select "Create Raid Set " from the "Raid Set Function" dialog box.
3. A "Select SATA Drive For Raid set" window is displayed showing the SATA drives connected to the current controller. Press the **UP** and **DOWN** arrow keys to select specific physical drives. Press the **Enter** key to associate the selected physical drive with the current RAID set. Repeat this step; the user can add as many disk drives as are available to a single RAID set.

When finish selecting SATA drives for RAID set, press the **Esc** key. A "Create Raid Set Confirmation" screen appears, select the **Yes** option to confirm it.




BIOS CONFIGURATION

4. An “Edit The Raid Set Name” dialog box appears. Enter 1 to 15 alphanumeric characters to define a unique identifier for the RAID set. The default RAID set name will always appear as Raid Set. #.




3.7.2.2 Delete Raid Set

To erase and reconfigure a RAID set completely, you must delete it and re-create the RAID set first. To delete a RAID set, select the RAID set number that user want to delete in the “Select Raid Set to Delete” screen. The “Delete Raid Set” dialog box appears, then press **Yes** option to delete it. Warning, data on RAID set will be lost if this option is used.



BIOS CONFIGURATION

3.7.2.3 Expand Raid Set



Instead of deleting a RAID set and recreating it with additional disk drives, the "Expand Raid Set" function allows the users to add disk drives to the RAID set that have already been created. To expand a RAID set:

Select the "Expand Raid Set" option. If there is an available disk, then the "Select SATA Drives For Raid Set Expansion" screen appears.

Select the target RAID set by clicking on the appropriate radio button. Select the target disk by clicking on the appropriate check box.


Press the **Yes** option to start the expansion on the RAID set. The new additional capacity can be utilized by one or more volume sets. The volume sets associated with this RAID set appear for you to have chance to modify RAID level or stripe size. Follow the instruction presented in the "Modify Volume Set " to modify the volume sets; operation system specific utilities may be required to expand operating system partitions.

Note:

1. Once the "Expand Raid Set" process has started, user can not stop it. The process must be completed.
2. If a disk drive fails during raid set expansion and a hot spare is available, an auto rebuild operation will occur after the RAID set expansion completes.

BIOS CONFIGURATION

- Migrating




Migration occurs when a disk is added to a RAID set. Migrating state is displayed in the RAID state area of "The Raid Set Information" screen when a disk is being added to a RAID set. Migrating state is also displayed in the associated volume state area of the "Volume Set Information" which belongs this RAID set.

3.7.2.4 Activate Incomplete Raid Set

The following screen is used to activate the RAID set after one of its disk drive was removed in the power off state.

When one of the disk drives is removed in power off state, the RAID set state will change to "Incomplete State". If a user wants to continue to work while the external RAID adapter is powered on, the user can use the "Activate Raid Set" option to active the RAID set. After user selects this function, the RAID state will change to "Degraded Mode".


BIOS CONFIGURATION



3.7.2.5 Create Hot Spare

When you choose the “Create Hot Spare” option in the “Raid Set Function”, all unused physical devices connected to the current controller will result in the following:

Select the target disk by clicking on the appropriate check box. Press the **Enter** key to select a disk drive and press **Yes** option in the “Create Hot Spare” to designate it as a hot spare. The “Create Hot Spare” option gives you the ability to define a global hot spare.




BIOS CONFIGURATION

3.7.2.6 Delete Hot Spare

Select the target hot spare disk to delete by clicking on the appropriate check box.


Press the **Enter** keys to select a hot spare disk drive, and press **Yes** in the “Delete Hot Spare” screen to delete the hot spare.



3.7.2.7 Raid Set Information


To display RAID set information, move the cursor bar to the desired RAID set number, then press the **Enter** key. The “Raid Set Information” will display.

You can only view information for the RAID set in this screen.



3.7.3 Volume Set Function

A volume set is seen by the host system as a single logical device; it is organized in a RAID level within the controller utilizing one or more physical disks. RAID level refers to the level of data performance and protection of a volume set. A volume set can consume all of the capacity or a portion of the available disk capacity of a RAID set. Multiple volume sets can exist on a RAID set. If multiple volume sets reside on a specified RAID set, all volume sets will reside on all physical disks in the RAID set. Thus each volume set on the RAID set will have its data spread evenly across all the disks in the RAID set. This is with regards in having more than one volume set using some of the available disks and another volume set using other disks.




3.7.3.1 Create Volume Set

1. Volume sets of different RAID levels may coexist on the same RAID set.
2. Up to 16 volume sets can be created by the external RAID adapter.
3. The maximum addressable size of a single volume set is not limited to 2TB because the controller is capable of 64-bit mode. However, the operating system itself may not be capable of addressing more than 2TB.


To create a volume set, follow the following steps:

1. Select the "Volume Set Function" from the main menu.
2. Choose the "Create Volume Set" from "Volume Set Function" dialog box screen.

BIOS CONFIGURATION




3. The "Create Volume From RAID Set" dialog box will be appeared. This screen displays the existing arranged RAID sets. Select the RAID set number and press the **Enter** key. The "Volume Creation" dialogue is displayed in the screen.
4. A window with a summary of the current volume set's settings. The "Volume Creation" option allows user to select the Volume Name, Capacity, RAID Level, Stripe Size, SCSI Channel/SCSI ID/SCSI LUN, Cache Mode and Tag Queuing. The user can modify the default values in this screen; the modification procedures are in section 3.5.3.3.



5. After completing the modification of the volume set, press the **Esc** key to confirm it. An "Initialization" screen is presented.
- Select "Foreground (Faster Completion)" for faster initialization of the selected volume set.
 - Select "Background (Instant Available)" for normal initialization of the selected volume set.


BIOS CONFIGURATION



- Select "No Init (To Rescue Volume)" for no initialization of the selected volume set.
6. Repeat steps 3 to 5 to create additional volume sets.
 7. The initialization percentage of volume set will be displayed at the bottom line.

• Volume Name

The default volume name will always appear as Volume Set #. You can rename the volume set providing it does not exceed the 15 characters limit.




• Raid Level

Set the RAID level for the volume set. Highlight RAID Level and press **Enter**.

BIOS CONFIGURATION


The available RAID levels for the current volume set are displayed. Select a RAID level and press the **Enter** key to confirm.



● Capacity

The maximum available volume size is the default value for the first setting. Enter the appropriate volume size to fit your application. The capacity value can be increased or decreased by the **UP** and **DOWN** arrow keys. The capacity of each volume set must be less than or equal to the total capacity of the RAID set on which it resides.

If volume capacity will exceed 2TB, controller will show the "Greater Two TB Volume Support" sub-menu.



BIOS CONFIGURATION

- **No**

It keeps the volume size with max. 2TB limitation.

- **LBA 64**

This option uses 16 bytes CDB instead of 10 bytes. The maximum volume capacity supports up to 512TB.

This option works on different OS which supports 16 bytes CDB.

Such as:


Windows 2003 with SP1

Linux kernel 2.6.x or latter

- **For Windows**

It change the sector size from default 512 Bytes to 4k Bytes. the maximum volume capacity up to 16TB.

This option works under Windows platform only. And it can not be converted to Dynamic Disk, because 4k sector size is not a standard format.




For more details please download PDF file from ftp://ftp.areca.com.tw/RaidCards/Documents/Manual_Spec/Over2TB_050721.zip

BIOS CONFIGURATION


● Stripe Size

This parameter sets the size of segment written to each disk in a RAID 0, 1, 10, 5, or 6 logical drive. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB.



● SCSI Channel


The external RAID adapter function simulates a SCSI RAID controller. The host bus represents the SCSI channel. Choose the "SCSI Channel". A "Select SCSI Channel" dialog box will appear; select the channel number and press the **Enter** key to confirm it.



BIOS CONFIGURATION


● SCSI ID

Each device attached to the SATA card, as well as the card itself, must be assigned a unique SCSI ID number. A SCSI channel can connect up to 15 devices. It is necessary to assign a SCSI ID to each device from a list of available SCSI IDs.



● SCSI LUN


Each SCSI ID can support up to 8 LUNs. Most external RAID adapters treat each LUN as if it were a SATA disk.



BIOS CONFIGURATION


- **Cache Mode**

User can set the cache mode to either “Write Through” or “Write Back” cache.



- **Tag Queuing**


This option, when enabled, can enhance overall system performance under multi-tasking operating systems. The Command Tag (Drive Channel) function controls the SCSI command tag queuing support for each drive channel. This function should normally remain enabled. Disable this function only when using older drives that do not support command tag queuing.



BIOS CONFIGURATION

3.7.3.2 Delete Volume Set


To delete volume set from a RAID set, move the cursor bar to the "Delete Volume Set" item, then press the **Enter** key. The "Volume Set Functions" menu will show all Raid Set # items. Move the cursor bar to a RAID set number, then press the **Enter** key to show all volume sets within that RAID set. Move the cursor to the volume set number that is to be deleted and press **Enter** key to delete it.



3.7.3.3 Modify Volume Set

Use this option to modify volume set configuration. To modify volume set values from RAID set system function, move the cursor bar to the "Modify Volume Set" item, then press the **Enter** key. The "Volume Set Functions" menu will show all RAID set items. Move the cursor bar to a RAID set number item, then press the **Enter** key to show all volume set items. Select the volume set from the list to be changed, press the **Enter** key to modify it.

BIOS CONFIGURATION



As shown, volume information can be modified at this screen. Choose this option to display the properties of the selected volume set; all values can be modified except only the last volume set capacity of the expand RAID set.

3.7.3.3.1 Volume Growth

Use "Expand RAID Set" function to add disk to a RAID set. The additional capacity can be used to enlarge the last volume set size or to create another volume set. The "Modify Volume Set" function can support the "Volume Modification" function. To expand the last volume set capacity, move the cursor bar to the "Capacity" item and entry the capacity size. When finished the above action, press the **ESC** key and select the **Yes** option to complete the action. The last volume set starts to expand its capacity.

To expand an existing volume noticed:

- Only the last volume can expand capacity.
- When expand volume capacity, you can't modify stripe size or modify RAID level simultaneously.
- You can expand volume capacity, but can't reduce volume capacity size.
- After volume expansion, the volume capacity can't be decreased.


BIOS CONFIGURATION

For greater 2TB expansion:

- If your system installed in the volume, don't expand the volume capacity greater 2TB, currently OS can't support boot up from a greater 2TB capacity device.
- Expand over 2TB used LBA64 mode. Please make sure your OS supports LBA64 before expand it.

3.7.3.3.2 Volume Set Migration


Migrating occurs when a volume set is migrating from one RAID level to another, when a volume set strip size changes, or when a disk is added to a RAID set. Migration status is displayed in the volume state area of the "Volume Set Information" screen.



3.7.3.4 Check Volume Set

Use this option to verify the correctness of the redundant data in a volume set. For example, in a system with a dedicated parity disk drive, a volume set check entails computing the parity of the data disk drives and comparing those results to the contents of the dedicated parity disk drive. To check volume set, move the cursor bar to the "Check Volume Set" item, then press the **Enter** key. The "Volume Set Functions" menu will show all RAID set number items. Move the cursor bar to a RAID set number item and then press the **Enter** key to show all volume set items. Select the volume set to be checked from the list and press **Enter** key to select it. After completing the selection, the confirmation screen appears, press **Yes** option to start the check.

BIOS CONFIGURATION




3.7.3.5 Stop Volume Set Check

Use this option to stop all of the “Check Volume Set” operations.


3.7.3.6 Display Volume Set Info.

To display volume set information, move the cursor bar to the desired volume set number and then press the **Enter** key. The “Volume Set Information” screen will be shown. You can only view the information of this volume set in this screen.




BIOS CONFIGURATION

3.7.4 Physical Drives



Choose this option from the main menu to select a physical disk and perform the operations listed above.


3.7.4.1 View Drive Information



BIOS CONFIGURATION

When you choose this option, the physical disks connected to the external RAID adapters are listed. Move the cursor to the desired drive and press **Enter** to view drive information.

3.7.4.2 Create Pass-Through Disk




A pass-through disk is not controlled by the external RAID adapter firmware and thus can't be a part of a volume set. The disk is available directly to the operating system as an individual disk. It is typically used on a system where the operating system is on a disk not controlled by the external RAID adapters firmware. The SCSI Channel, SCSI ID, SCSI LUN, Cache Mode, and Tag Queuing must be specified to create a pass-through disk.

3.7.4.3 Modify a Pass-Through Disk

Use this option to modify pass-through disk attributes. To select and modify a pass-through disk from the pool of pass-through disks, move the cursor bar to the "Modify Pass-Through Drive" option and then press the **Enter** key. The "Physical Drive Function" menu will show all pass-through drive number options. Move the cursor bar to the desired item and then press the **Enter** key to show all pass-through disk attributes. Select the parameter from the list to be changed and then press the **Enter** key to modify it.


BIOS CONFIGURATION

3.7.4.4 Delete Pass-Through Disk



To delete a pass-through drive from the pass-through drive pool, move the cursor bar to the "Delete Pass-Through Drive" item, then press the **Enter** key. The "Delete Pass-Through confirmation" screen will appear; select **Yes** option to delete it.

3.7.4.5 Identify Selected Drive




You can use the "Identify Selected Drive" feature to prevent removing the wrong drive, the selected drive fault LED will blank when the "Identify Selected Drive" is selected.


BIOS CONFIGURATION

3.7.5 Raid System Function

To set the RAID system function, move the cursor bar to the main menu and select the "Raid System Function" item and then press **Enter** key. The "Raid System Function" menu will show multiple items. Move the cursor bar to an item, then press **Enter** key to select the desired function.




3.7.5.1 Mute The Alert Beeper




The "Mute The Alert Beeper" function item is used to control the External RAID adapter beeper. Select **Yes** option and press the **Enter** key in the dialog box to turn the beeper off temporarily. The beeper will still activate on the next event.

BIOS CONFIGURATION

3.7.5.2 Alert Beeper Setting



The "Alert Beeper Setting" item is used to "Disable" or "Enable" the External RAID adapter alarm tone generator. Select "Disabled" and press the **Enter** key in the dialog box to turn the beeper off.



3.7.5.3 Change Password


The manufacture default password is set to 0000. The password option allows user to set or clear the password protection feature. Once the password has been set, the user can

BIOS CONFIGURATION

monitor and configure the controller only by providing the correct password. This feature is used to protect the SATA RAID system from unauthorized access. The adapter will check the password only when entering the main menu from the initial screen. The system will automatically go back to the initial screen if it does not receive any command in 5 minutes. To set or change the password, move the cursor to "Raid System Function" screen, press the "Change Password" item. The "Enter New Password" screen will appear. Do not use spaces when you enter the password, If spaces are used, it will lock out the user. To disable the password, only press **Enter** key in both the "Enter New Password" and "Re-Enter New Password" column. The existing password will be cleared. No password checking will occur when entering the main menu.


3.7.5.4 JBOD/RAID Function

JBOD is an acronym for "Just a Bunch Of Disk". A group of hard disks in a RAID controllers are not set up as any type of RAID configuration. All drives are available to the operating system as an individual disk. JBOD does not provide data redundancy. User needs to delete the RAID set, when you want to change the option from the RAID to the JBOD function.




BIOS CONFIGURATION

3.7.5.5 Background Task Priority



The “Background Task Priority” is a relative indication of how much time the controller devotes to a rebuild operation. The External RAID adapter allows the user to choose the rebuild priority (Ultralow, Low, Normal, High) to balance volume set access and rebuild tasks appropriately.

3.7.5.6 Maximum SATA Mode




The external RAID adapter can support up to SATA II, which runs up to 300MB/s, twice as fast as SATA150. NCQ is a command protocol in Serial ATA that can only be implemented on

BIOS CONFIGURATION

native Serial ATA hard drives. It allows multiple commands to be outstanding within a drive at the same time. Drives that support NCQ have an internal queue where outstanding commands can be dynamically rescheduled or re-ordered, along with the necessary tracking mechanisms for outstanding and completed portions of the workload. The external RAID adapter allows the user to choose the SATA Mode: SATA150, SATA150+NCQ, SATA300, SATA300+NCQ.

3.7.5.7 HDD Read Ahead Cache




Allow Read Ahead (Default: Enabled)—When Enabled, the drive's read ahead cache algorithm is used, providing maximum performance under most circumstances.

3.7.5.8 Volume Data Read Ahead

The volume read data ahead parameter specifies the controller firmware algorithms which process the Read Ahead data blocks from the disk. The Read Ahead parameter is normal by default. To modify the value, you must set it from the command line using the Read Ahead option. The default normal option satisfies the performance requirements for a typical volume. The disabled value implies no read ahead. The most efficient value for the controllers depends on your application. Aggressive read ahead is optimal for sequential access but it degrades random access.

BIOS CONFIGURATION




3.7.5.9 Stagger Power On

In a PC system with only one or two drives, the power can supply enough power to spin up both drives simultaneously. But in systems with more than two drives, the startup current from spinning up the drives all at once can overload the power supply, causing damage to the power supply, disk drives and other system components. This damage can be avoided by allowing the host to stagger the spin-up of the drives. New SATA drives have support stagger spin-up capabilities to boost reliability. Stagger spin-up is a very useful feature for managing multiple disk drives in a storage subsystem. It gives the host the ability to spin up the disk drives sequentially or in groups, allowing the drives to come ready at the optimum time without straining the system power supply. Staggering drive spin-up in a multiple drive environment also avoids the extra cost of a power supply designed to meet short-term startup power demand as well as steady state conditions.


Areca RAID adapter has included the option for customer to select the disk drives sequentially stagger power up value. The values can be selected from 0.4s to 6s per step which powers up one drive.

BIOS CONFIGURATION



3.7.5.10 Empty HDD slot HDD

The firmware has added the "Empty HDD Slot LED" option to setup the fault LED light "ON "or "OFF" when there is no HDD installedon this slot. When each slot has a power LED for the HDD installed identify, user can set this option to "OFF". Choose option "ON", the RAID adapter will light the fault LED; if no HDD installed.




BIOS CONFIGURATION

3.7.5.11 HDD SMART Status Polling

An external RAID enclosure has the hardware monitor in the dedicated backplane that can report HDD temperature status to the controller. However, PCI cards do not use backplanes if the drives are internal to the main server chassis. The type of enclosure cannot report the HDD temperature to the controller. For this reason, "HDD SMART Status Polling" was added to enable scanning of the HDD temperature function. It is necessary to enable "HDD SMART Status Polling" function before SMART information is accessible. This function is disabled by default.

The following screen shot shows how to change the McBIOS RAID manager setting to enable the polling function.




3.7.5.12 Controller Fan Detection

Included in the product box is a field replaceable passive heatsink to be used only if there is enough airflow to adequately cool the passive heatsink.

The "Controller Fan Detection" function is available in the version 1.36 date: 2005-05-19 and later for preventing the Buzzer warning. When using the passive heatsink, disable the "Controller Fan Detection" function through this McBIOS RAID manager setting.


The following screen shot shows how to change the McBIOS RAID manager screen setting to disable the beeper function. **(This function is not available in the web browser setting.)**

BIOS CONFIGURATION



3.7.5.13 Auto Activate Raid Set

When some of the disk drives are removed in power off state or boot up stage, the RAID set state will change to “Incomplete State”.




But if a user wants to automatically continue to work while the external RAID adapter is powered on, then user can set the “Auto Activate Raid Set” option to “Enabled”. The RAID state will change to “Degraded Mode” while it powers on.

BIOS CONFIGURATION

3.7.5.14 Disk Write Cache Mode


User can set the "Disk Write Cache Mode" to Auto, Enabled, or Disabled. "Enabled" increases speed, "Disabled" increases reliability.



3.7.5.15 Capacity Truncation

External RAID adapter use drive truncation so that drives from differing vendors are more likely to be able to be used as spares for each other. Drive truncation slightly decreases the usable capacity of a drive that is used in redundant units.

The controller provides three truncation modes in the system configuration: "Multiples Of 10G", "Multiples Of 1G", and "No Truncation".



BIOS CONFIGURATION


Multiples Of 10G: If you have 120 GB drives from different vendors; chances are that the capacity varies slightly. For example, one drive might be 123.5 GB, and the other 120 GB. "Multiples Of 10G" truncates the number under tens. This makes the same capacity for both of these drives so that one could replace the other.

Multiples Of 1G: If you have 123 GB drives from different vendors; chances are that the capacity varies slightly. For example, one drive might be 123.5 GB, and the other 123.4 GB. "Multiples Of 1G" truncates the fractional part. This makes the same capacity for both of these drives so that one could replace the other.

No Truncation: It does not truncate the capacity.

3.7.6 Ethernet Configuration (ARC-1202)


Use this feature to set the controller Ethernet port configuration. It is not necessary to create reserved disk space on any hard disk for the Ethernet port and HTTP service to function; these functions are built into the controller firmware. To choose the "Ethernet Configuration" of the controller, move the cursor bar to the main menu "Ethernet Configuration" function item and then press the **Enter** key.



BIOS CONFIGURATION

3.7.6.1 DHCP Function

DHCP (Dynamic Host Configuration Protocol) allows network administrators centrally manage and automate the assignment of IP (Internet Protocol) addresses on a computer network. When using the TCP/IP protocol (Internet protocol), it is necessary for a computer to have a unique IP address in order to communicate to other computer systems. Without DHCP, the IP address must be entered manually at each computer system. DHCP lets a network administrator supervise and distribute IP addresses from a central point. The purpose of DHCP is to provide the automatic (dynamic) allocation of IP client configurations for a specific time period (called a lease period) and to minimize the work necessary to administer a large IP network. To configure the DHCP function of the controller, move the cursor bar to "DHCP Function" item, then press **Enter** key to show the DHCP setting. Select the "Disabled" or "Enabled" option to enable or disable the DHCP function. If DHCP is disabled, it will be necessary to manually enter a static IP address that does not conflict with other devices on the network.




3.7.6.2 Local IP address

If you intend to set up your client computers manually (no DHCP), make sure that the assigned IP address is in the same range as the default router address and that it is unique to your private network. However, it is highly recommend to use DHCP if that option is available on your network. An IP address allocation scheme will reduce the time it takes to set-up client com-


BIOS CONFIGURATION

puters and eliminate the possibilities of administrative errors and duplicate addresses. To manually configure the local IP address of the controller, move the cursor bar to “Local IP address” item, then press the **Enter** key to show the default address setting in the external RAID adapter. You can then reassign the static IP address of the adapter.



3.7.6.3 Ethernet Address

A MAC address stands for “Media Access Control” address and is unique to every single ethernet device. On an Ethernet LAN, it’s the same as your Ethernet address. When you’re connected to a local network from the external RAID adapter Ethernet port, a correspondence table relates your IP address to the external RAID adapter’s physical (MAC) address on the LAN.



BIOS CONFIGURATION

3.7.7 View System Events

To view the external RAID adapter's system events information, move the cursor bar to the main menu and select the "View System Events" link, then press the **Enter** key. The external RAID adapter's events screen will appear.

Controller I/O Port:F3000000h, F2: Select Controller, F10: Reboot System			
Areca Technology Corporation RAID Controller			
Main Menu			
Quick Volume/Raid Setup			
Time	Device	Event Type	ElapseTime Errors
2004-1-1 12:00:00	H/W Monitor	Raid Powered On	
2004-1-1 12:00:00	H/W Monitor	Raid Powered On	
2004-1-1 12:00:00	H/W Monitor	Raid Powered On	
ArrowKey Or AZ:Move Cursor, Enter: Select, ESC: Escape, L:Line Draw, X: Redraw			

Choose this option to view the system events information: Timer, Device, Event type, Elapsed Time, and Errors. The RAID system does not have a real time clock. The time information is the relative time from the external RAID adapter powered on.

3.7.8 Clear Events Buffer

Use this feature to clear the entire events buffer.


3.7.9 Hardware Monitor

To view the RAID adapter's hardware monitor information, move the cursor bar to the main menu and click the "Hardware Monitor" link. The hardware information screen appears.

The "The Hardware Monitor" provides the temperature and fan speed (I/O Processor fan) of the external RAID adapter. The ARC-1212x/1222x card interface lists two temperatures; one for the I/O processor and the other one for the controller. The I/O processor temperature is a new feature which detects by a


BIOS CONFIGURATION

thermal sensor under the IOP341. The processor safe range is 90 Celsius degree and the controller safe range is 70 Celsius degree. If any sensor detects over the safe ranges on these temperatures, you will get a warning event.



3.7.10 System Information

Choose this option to display main processor, CPU instruction cache and data cache size, firmware version, serial number, system memory/speed and controller model name. To check the system information, move the cursor bar to "System Information" item, then press **Enter** key. All relevant controller information will be displayed.



4. Driver Installation

This chapter describes how to install the external RAID adapter driver to your operating system. The installation procedures use the following terminology:

Installing operating system on the controller's volume

If you have a new drive configuration without an operating system and want to install operating system on a disk drive managed by the external RAID adapter. The driver installation is a part of the operating system installation.

Installing External RAID adapter into an existing operating system

The computer has an existing operating system installed and the external RAID adapter is being installed as a secondary controller.

Have all required system hardware and software components on hand before proceeding with the setup and installation.

Materials required:

- Microsoft Windows 2000/XP/2003/Vista/2008/Windows 7, Linux, FreeBSD or more installation CD
- External RAID adapter Device Drivers Software CD
- External RAID adapter

4.1 Creating the Driver Diskettes

The software CD disc shipped with the external RAID adapter is a self booting CD. In order to create driver diskettes for Windows, Linux, FreeBSD or more installation drivers, your system is required to support booting from the CD-ROM.

If you do not have the software CD disc with the package, contact your local dealer or you can also download the latest version drivers for Windows 2000/XP/2003/Vista/2008/Windows 7, Linux, FreeBSD and more from the Areca web site at <http://www.areca.com.tw>

DRIVER INSTALLATION

These driver diskettes are intended for use with new operating system installations. Determine the correct kernel version and identify which diskette images contain drivers for that kernel. If the driver file ends in .img, create the appropriate driver diskette using "dd" utility. The following steps are required to create the driver diskettes:

1. The computer system BIOS must be set to boot-up from the CD-ROM.
2. Insert the external RAID adapter Driver software CD disc into the CD-ROM drive.
3. The system will boot-up from CD-ROM Drive.

Note:

It will take about 5 minutes to boot up the Knoppix GNU/Linux, Live Linux CD.

4. To create the driver diskette, for example: making the CentOS 5 driver diskette.
 - a). Execute xterm by clicking the XTerm icon on left-bottom toolbar.
 - b). Change the path to the specific driver image.
`cd /cdrom/PACKAGES/Linux/DRIVER/CentOS_5`
 - c). Dump the driver image into floppy diskette using "dd" utility, Command format: `dd if=<image file> of=<destination>`
`dd if=driver.img of=/dev/fd0`
 - d). When the operation is complete, the following messages are shown.
2880+0 records in
2880+0 records out
1474560 bytes (1.5 MB) copied, 97.5903 seconds, 15.1 kB/s

The driver diskette is made now. Proceed to the following instruction for installation procedures.

4.2 Driver Installation for Windows

The external RAID adapter can be used with Microsoft Windows 2000/XP/2003/Vista/2008/Windows 7. The external RAID adapters support SCSI Miniport and StorPort Drivers for Windows Server 2003/Vista/2008/Windows 7.

4.2.1 New Storage Device Drivers in Windows 2003/Vista/2008/Windows 7

The Storport driver is new to Windows Server 2003/Vista/2008/Windows 7. Storport implements a new architecture designed for better performance in Storage Area Network (SAN) environments. Storport delivers higher I/O throughput, enhanced manageability, and an improved miniport interface. Storport better utilizes faster adapters through the use of reduced Delay Procedure Call (DPC) and improved queue management.

4.2.2 Installing Windows 2000/XP/2003/Vista/2008/Windows 7 on a Adapter Volume

The following instructions explain how to install the external RAID adapter device driver while installing Windows 2000/XP/2003/Vista/2008/Windows 7. Have your bootable Microsoft Windows 2000/XP/2003/Vista/2008/Windows 7 CD and follow the required procedure below to install external RAID adapter:

1. Make sure you follow the instructions in Chapter 2 "Hardware Installation" to install the controller and connect the disk drives or enclosure.
2. Start the system and then press **Tab/F6** to access the McBIOS RAID manager. Use the McBIOS RAID manager to configure the External RAID adapter to which you will install Windows. For details, see Chapter 3 "BIOS Configuration". Once the external RAID adapter has been configured, continue with next step to install the operating system.
3. Insert the Windows setup CD and reboot the system to begin the Windows installation.

DRIVER INSTALLATION

Note:

The computer system BIOS must support bootable from CD-ROM.

4. Press **F6** when the following displays at the bottom of the screen for only 5 seconds, unless you are installing Windows Vista and 2008.

"Press F6 if you need to install..."

This must be done or else the Windows installer will not prompt for the driver from the external RAID adapter and the driver diskette will not be recognized.

Note:

If you are installing Windows Vista/2008/Windows 7, click "Load Driver" to locate the device driver and then click "Next".

5. The next screen will show:

"Setup could not determine the type of one or more". Specify an additional external RAID adapter device driver by pressing **S**.

6. Insert the external RAID adapter driver diskette in drive "A:" and press **Enter**.

7. Select the appropriate external RAID adapter from the menu by using the arrow key to highlight it, and then press **Enter** to select it.

8. Setup will load support for the following mass storage devices: "ARECA[Windows X86-64 Storport] external RAID adapter". Press **Enter** continue and copy the driver files.

9. From this point on, simply follow the Microsoft Windows installation procedure. Follow the on-screen instructions, responding as needed, to complete the installation. Reboot the system to load the new driver/operating system.

4.2.3 Installing Adapter into an Existing Windows 2000/XP/2003/Vista/2008/Windows 7 Installation

In this scenario, you are installing the adapter in an existing Windows system. To install the driver:

1. Follow the instructions in Chapter 2, the “Hardware Installation” chapter, to install the adapter and connect the disk drives or enclosure.
2. Start the system and then press **Tab/F6** to enter the adapter Host_BIOS setup utility. Use the setup utility to configure the host adapter parameter. For details, see Chapter 3, BIOS Configuration. Once the host adapter miscellaneous settings properties configured, continue with installation of the driver.
3. Boot Windows and the OS will recognize the external RAID adapter and launch the “Found New Hardware Wizard”, which guides you in installing the external RAID adapter driver.
4. Choose “Display a list of known drivers for this device, so that you can choose a specific driver.” and click on “Next”.
5. Insert the external RAID adapter driver diskette or the shipping software CD and type-in or browse to the correct device driver path. Click the “Next”.
8. If the “Digital Signature Not Found” screen appears, click on “Continue” to continue the installation. This message informs you that a nonsigned driver is being installed.
9. Windows automatically copies the appropriate driver files and rebuilds its driver database.
10. Click the “Finish” button to complete the driver installation.
11. Remove the diskette from the drive and click **Yes** to restart the computer to load the new drivers.

DRIVER INSTALLATION

4.2.4 Making Volume Sets Available to Windows System

When you reboot the system, log in as a system administrator. The following steps show how to make any new disk arrays or independent disks accessible to Windows 2000/XP/2003/Vista/2008/Windows 7.

This procedure assumes that the external RAID adapter hardware, driver, and Windows are installed and operational in your system.

1. Partition and format the new disks using "Disk Administrator":
 - a). Choose "Administrative Tools" from the "Start" menu.
 - b). Choose "Computer Management" from the "Administrative Tools" menu.
 - c). Select "Storage".
 - d). Select "Disk Management".
2. Follow the on-screen prompts to write a signature to the drive.
3. Right click on the drive and select "Create Volume" from the menu.
4. Follow the on-screen prompts to create a volume set and to assign a disk drive letter.

4.2.5 Uninstalling Adapter from Windows 2000/XP/2003/Vista/2008/Windows 7

To remove the external RAID adapter driver from the Windows system, follow the instructions below.

1. Ensure that you have closed all applications and are logged in with administrative rights.
2. Start from "My Computer", click right side of the mouse. Select "Manage", then choose "Computer Management".

3. Select the "Device Manager", then choose "SCSI and RAID Controllers". Right click on the "ARECA(X86-64-STORPORT) external External RAID adapter" and click right side of mouse then select "Uninstall". A "Confirm Device Removal" screen appears.

4. Click **Yes** to remove the external RAID adapter driver.

4.3 Driver Installation for Linux

This chapter describes how to install the external RAID adapter driver to Red Hat Linux, and SuSE Linux. Before installing the external RAID adapter driver to the Linux, complete the following actions:

1. Install and configure the controller and hard disk drives according to the instructions in Chapter 2 Hardware Installation.
2. Start the system and then press **Tab+F6** to enter the McBIOS RAID manager configuration utility. Use the McBIOS RAID manager utility to create the RAID set and volume set. For details, see Chapter 3, McBIOS RAID Manager.

If you are using a Linux distribution for which there is not a compiled driver available from Areca, you can copy the source from the SATA software CD or download the source from the Areca website and compile a new driver.

Compiled and tested drivers for Red Hat and SuSE Linux are included on the shipped CD. You can download updated versions of compiled and tested drivers for Red Hat or SuSE Linux from the Areca web site at <http://www.areca.com.tw>. Included in these downloads is the Linux driver source, which can be used to compile the updated version driver for RedHat, SuSE and other versions of Linux.

Please refer to the "readme.txt" file on the included Areca software CD or website to make driver diskette and to install driver to the system.

DRIVER INSTALLATION

4.4 Driver Installation for FreeBSD

This chapter describes how to install the external External RAID adapter driver to FreeBSD. Before installing the external RAID adapter driver to FreeBSD, complete following actions:

1. Install and configure the controller and hard disk drives according to the instructions in Chapter 2, Hardware Installation.
2. Start the system and then press **Tab+F6** to enter the McBIOS RAID Manager configuration utility. Use the McBIOS RAID manager utility to create the raid set and volume set. For details, see Chapter 3, McBIOS RAID Manager.

The supplied software CD that came with the external RAID adapter includes compiled and tested drivers for FreeBSD 4.x (4.2 and onwards) and 5.x (5.2 and onwards). To check if a more current version driver is available, please see the Areca web site at <http://www.areca.com.tw>.

Please refer to the "readme.txt" file on the external RAID adapter software CD or website to make driver diskette and to install driver to the system.

4.5 Driver Installation for Solaris 10

Please refer to the "readme.txt" file on the software CD or a manual from website: <http://www.areca.com.tw>

4.6 Driver Installation for Mac 10.x

You must have administrative level permissions to install Areca Mac driver & application. Apple OS X 10.5.x/10.6.x has default integrated Areca driver for supporting its line of Intel IOP based SATA RAID and SAS RAID host adapters. You can install application on your Power Mac G5 or Mac Pro as below:

1. Insert the Areca Mac driver & software CD that came with your external RAID adapter.
2. Double-click on the following file that resides at
<CD-ROM>\packages\MacOS\Application\
Leopard_Tiger or Snow_leopard\

DRIVER INSTALLATION

Installer a). install_mraid.zip

3. Launch the installer by double-clicking the install_mraid on the Finder.
4. Follow the installer steps to install archttp64 and arc_cli utility at the same time.
5. Reboot your Power Mac G5 or Mac Pro system.

Normally archttp64 and arc_cli are installed at the same time on Areca external RAID adapter. Once archttp64 and arc_cli have been installed, the background task automatically starts each time when you start your computer. There is one MARID icon showing on your desktop. This icon is for you to start up the McRAID storage manager (by archttp64) and arc_cli utility. You can also only upgrade the driver, archttp64 or arc_cli individual item that resides the command line. You can download arc-cli manual from Areca.



4.7 Driver Installation for UnixWare 7.1.4

Please refer to the "readme.txt" file on the software CD or a manual from website: <http://www.areca.com.tw>

4.8 Driver Installation for NetWare 6.5

Please refer to the "readme.txt" file on the software CD or a manual from website: <http://www.areca.com>.

5. ArcHttp Proxy Server Installation

Overview

After hardware installation, the SATA disk drives connected to the external RAID adapter must be configured and the volume set units initialized before they are ready to use.

The user interface for these tasks can be accessed through the built-in configuration that resides in the controller's firmware. It provides complete control and management of the controller and disk arrays, eliminating the need for additional hardware or software.

In addition, a software utility to configure the external RAID adapter is provided on the CD delivered with SATA adapter. This software CD contains the software utility that can monitor, test, and support the external RAID adapter. The software utility and McRAID storage manager can configure and monitor the external RAID adapter via ArcHttp proxy server. The following table outlines their functions:

Configuration Utility	Operating System Supported
McBIOS RAID Manager	OS-Independent
McRAID Storage Manager (Via Archttp proxy server)	Windows 2000/XP/2003/Vista/2008/Windows 7, Linux, FreeBSD, Solaris and Mac
SAP Monitor (Single Admin portal to scan for multiple RAID units in the network, Via ArchHttp Proxy Server)	Windows 2000/XP/2003/Vista/2008/Windows 7

From version 1.6 and later, the HTTP management software (ArcHttp) runs as a service or daemon, and have it automatically start the proxy for all controllers found. This way the controller can be managed remotely without having to sign in the server. The HTTP management software (ArcHttp) also has integrated the General Configuration, Mail Configuration and SNMP Configuration. Those can be configured in local or remote standard web browser.

Note:

If your adapter have onboard LAN port, you do not need to install ArcHttp proxy server, you can use McRAID storage manager directly.


ARCHTTP PROXY SERVER INSTALLATION

5.1 For Windows

You must have administrative level permissions to install external RAID adapter software. This procedure assumes that the external RAID adapter hardware and Windows are installed and operational in your system.

Screen captures in this section are taken from a Windows XP installation. If you are running another version of Windows, your installation screen may look different, but the ArchHttp proxy server installation is essentially the same.


1. Insert the RAID adapter software CD in the CD-ROM drive.
2. Run the setup.exe file that resides at: <CD-ROM>\PACKAGES\Windows\http\setup.exe on the CD-ROM.
3. The screen shows "Preparing to Install".



Follow the on-screen prompts to complete ArchHttp proxy server software installation.

A program bar appears that measures the progress of the ArchHttp setup. When this screen complete, you have completed the ArchHttp proxy server software setup.

4. After a successful installation, the "Setup Complete" dialog box is displayed.




Click the "Finish" button to complete the installation.

ARCHTTP PROXY SERVER INSTALLATION

Click on the "Start" button in the Windows task bar and then click "Program", select the "McRAID" and run " ArchHttp proxy server". The ArchHttp proxy server dialog box appears.

1. When you select "Controller#01(PCI)" then click "Start" button. Then web browser McRAId storage manager appears.
2. If you select "Cfg Assistant" then click "Start" button. The "ArchHttp Configuration" appears. (Please refer to section 5.6 ArchHttp Configuration)



5.2 For Linux

You should have administrative level permissions to install external RAID adapter software. This procedure assumes that the external RAID adapter hardware and Linux are installed and operational in your system.

The following details the Linux installation procedure of the external RAID adapter software.

The ArchHttp proxy server is provided on the software CD delivered with SATA card or download from the www.areca.com.tw. The firmware embedded McRAID storage manager can configure and monitor the External RAID adapter via ArchHttp Proxy Server.

1. Login as root. Copy the ArchHttp file to a local directory.
- (1). Insert the external RAID adapter CD in the CD-ROM drive.

ARCHTTP PROXY SERVER INSTALLATION

(2). Copy <CD-ROM>\PACKAGES\Mac\http directory to local (Ex:/usr/local/sbin).

Or

(1). Download from the www.areca.com.tw or from the email attachment.

2. You must have administrative level permissions to install external RAID adapter ArchHttp proxy server software. This procedure assumes that the external RAID adapter hardware and driver are installed and operational in your system.

The following details are the installation procedure of the external RAID adapter for Linux ArchHttp proxy server software.

(1).Run the Archhttp proxy server by using the following command:

Usage: ./archhttp32 (TCP_PORT) or ./archhttp64 (TCP_PORT). It depends on your OS version.

Parameters: TCP_PORT value= 1~65535 (If TCP_PORT assigned, Archhttp will start from this port. Otherwise, it will use the setting in the archhttpsrv.conf or default 81). This is the port address assigning for the first adapter.

Such as: archhttp64 1553

(2). Archhttp server console started, controller card detected then ArchHttp proxy server screen appears.

Copyright (c) 2004 Areca, Inc. All Rights Reserved.

Areca HTTP proxy server V1.80.240 for Areca RAID adapters.

Controller(s) list

Controller[1](PCI) : Listen to port[1553].

Cfg Assistant : Listen to port[1554].

Binding IP:[0.0.0.0]

Note: IP[0.0.0.0] stands for any ip bound to this host.

#####

Press CTRL-C to exit program!!

#####

Controller [1] Http: New client [9] accepted

ARCHTTP PROXY SERVER INSTALLATION

Controller [1] Http: New Recv 243 bytes

Controller [1] Http: Send [174] bytes back to the client

(3). If you need the “Cfg Assistant”, please refer to section 5.6 ArchHttp Configuration.

(4). See the next chapter detailing the McRAID storage manager to customize your RAID volume set.

5.3 For FreeBSD

You should have administrative level permissions to install external RAID adapter software. This procedure assumes that the external RAID adapter hardware and FreeBSD are installed and operational in your system.

The following details FreeBSD installation procedure of the external RAID adapter software.

1. Insert the RAID adapter CD in the CD-ROM drive.
2. Copy <CD-ROM>\PACKAGES\FreeBSD\http directory to local
The next following step is the same with Linux. Please see section 5.2 For Linux.

5.4 For Solaris 10 x86

You must have administrative level permissions to install external RAID adapter software. This procedure assumes that the external RAID adapter hardware and FreeBSD are installed and operational in your system.

The following details Solaris installation procedure of the external RAID adapter software.

1. Insert the RAID adapter CD in the CD-ROM drive.
2. Copy <CD-ROM>\PACKAGES\Solaris\http directory to local
The next following step is the same with Linux. Please see section 5.2 For Linux.

ARCHTTP PROXY SERVER INSTALLATION

5.5 For Mac OS 10.x

The ArchHttp proxy server is provided on the software CD delivered with SATA card or download from the www.areca.com.tw. The firmware embedded McRAID storage manager can configure and monitor the external RAID adapter via ArchHttp proxy server. The Archhttp proxy server for Mac, please reference Chapter 4.6 Driver Installation for Mac 10.x or refer to the the Mac_manual_xxxx.pdf that resides at CD <CD-ROM>\DOCS directory. You can install driver, archhttp64 and arc-cli from software CD < CD >\package\ Mac OS directory at the same time.

5.6 ArchHttp Configuration

The ArchHttp proxy server will automatically assign one additional port for setup its configuration. If you want to change the "archhttp-srv.conf" setting up of ArchHttp configuration, For example: General Configuration, Mail Configuration, and SNMP Configuration, please start web browser by entering `http://[computer IP address]:[cfg port number]`

The screenshot displays the 'ARCHTTP Configurations' web interface. On the left, there is a sidebar with three links: 'General Configuration' (highlighted), 'Mail Configuration', and 'SNMP Trap Configuration'. The main content area is titled 'General Configurations' and contains several configuration fields:

- 'Binding IP' is a dropdown menu currently showing '0.0.0.0'. A list of available IP addresses is visible: '0.0.0.0', '127.0.0.1', and '192.168.0.44'.
- 'HTTP Port#' is a text input field.
- 'Display HTTP Connection Information To Console' is a checkbox.
- 'Scanning PCI Device' has radio buttons for 'Yes' (selected) and 'No'.
- 'Scanning RS-232 Device' has radio buttons for 'Yes' (selected) and 'No'.
- 'Scanning Inband Device' has radio buttons for 'Yes' (selected) and 'No'.

At the bottom of the configuration area, there is a checkbox labeled 'Confirm The Operation' and two buttons: 'Submit' and 'Reset'.

The ArchHttp configuration starts.

● General Configuration

Binding IP 0.0.0.0: You can choose either local administration or remote administration to connect web browser.

Binding IP 127.0.0.1: Using local administration to connect web browser.

Binding IP 192.166.0.44: Using remote administration to connect web browser.

ARCHTTP PROXY SERVER INSTALLATION

HTTP Port#: Value 1~65535

Display HTTP Connection Information To Console: Select **Yes** to show Http send bytes and receive bytes information in the console.

Scanning PCI Device: Select "Yes" for ARC-1XXX series adapter

Scanning RS-232 Device: No

Scanning Inband Device: No

• Mail Configuration

When you open the mail configuration page, you will see following settings:

SMTP server IP Address: Enter the SMTP server IP address which is not McRAID storage manager IP. Ex: 192.168.0.2

Sender Name: Enter the sender name that will be shown in the outgoing mail. Ex: RaidController_1

Mail address: Enter the sender email that will be shown in the outgoing mail, but don't type IP to replace domain name.

Ex: RaidController_1@areca.com.tw

Account: Enter the valid account if your SMTP mail server need authentication.

ARCHTTP Configurations

[General Configuration](#)

[Mail Configuration](#)

[SNMP Trap Configuration](#)

SMTP Server Configuration	
SMTP Server IP Address: <input type="text"/>	
Mail Address Configurations	
Sender Name: <input type="text"/>	Mail Address: <input type="text"/>
Account: <input type="text"/>	Password: <input type="text"/>
MailTo Name1: <input type="text"/>	Mail Address: <input type="text"/>
MailTo Name2: <input type="text"/>	Mail Address: <input type="text"/>
MailTo Name3: <input type="text"/>	Mail Address: <input type="text"/>
MailTo Name4: <input type="text"/>	Mail Address: <input type="text"/>
Event Notification Configurations	
<input checked="" type="radio"/> Disable Event Notification	No Event Notification Will Be Sent
<input type="radio"/> Urgent Error Notification	Send Only Urgent Event
<input type="radio"/> Serious Error Notification	Send Urgent And Serious Event
<input type="radio"/> Warning Error Notification	Send Urgent, Serious And Warning Event
<input type="radio"/> Information Notification	Send All Event
<input type="checkbox"/> Notification For No Event	Notify User If No Event Occurs Within 24 Hours
<input type="checkbox"/> Confirm The Operation	
<input type="button" value="Submit"/> <input type="button" value="Reset"/>	

ARCHTTP PROXY SERVER INSTALLATION

Note:

Please make sure you have completed mail address before you submit mail configurations.

Password: Enter the valid password if your SMTP mail server need authentication.

MailTo Name: Enter the alert receiver name that will be shown in the outgoing mail.

Mail Address: Enter the alert receiver mail address.
Ex: admin@areca.com.tw

• SNMP Trap Configuration

Please refer to the 6.8.4 SNMP configuration section.

Configure configuration and submit. After ArchHttp configurations have successfully submitted, the Archttp console restarts again.

ARCHTTP Configurations

[General Configuration](#)

[Mail Configuration](#)

[SNMP Trap Configuration](#)

SNMP Trap Configurations

SNMP Trap IP Address #1	192	168	0	173	port# 162
SNMP Trap IP Address #2	0	0	0	0	port# 162
SNMP Trap IP Address #3	0	0	0	0	port# 162

SNMP System Configurations

Community public

SNMP Trap Notification Configurations

<input type="radio"/> Disable Event Notification	No Event Notification Will Be Sent
<input checked="" type="radio"/> Urgent Error Notification	Send Only Urgent Event
<input type="radio"/> Serious Error Notification	Send Urgent And Serious Event
<input type="radio"/> Warning Error Notification	Send Urgent, Serious And Warning Event
<input type="radio"/> Information Notification	Send All Event

☐ Confirm The Operation

Submit Reset

Note:

Event Notification Table refer to Appendix D.
After you confirm and submit configurations, you can use "Generate Test Event" feature to make sure these settings are correct.

6. Web Browser-based Configuration

Before using the firmware-based browser McRAID storage manager utility, do the initial setup and installation of this product. If you need to boot up the operating system from a volume set, you must first create a RAID volume by using McBIOS RAID Manager. Please refer to section 3.3 Using Quick Volume /Raid Setup Configuration for information on creating this initial volume set.

The McRAID storage manager is firmware-based utility, which is accessible via the browser installed on your operating system. The web browser-based McRAID storage manager is a HTML-based application, which utilizes the browser (IE, Netscape and Mozilla etc) installed on your monitor station.

It can be accessed through the In-Band PCI-X/PCIe bus or Out-of-Band Ethernet port. The In-Band method via archhttp proxy server to launch the web browser-based McRAID storage manager. The firmware-embedded web browser-based McRAID storage manager allows local or remote to access it from any standard internet browser via a LAN or WAN with no software or patches required. The firmware contains SMTP manager monitors all system events and user can select either single or multiple user notifications to be sent via LAN with "Plain English" e-mails. The firmware-embedded SNMP agent allows remote to monitor events via LAN with no SNMP agent required.

- Create RAID set,
- Expand RAID set,
- Define volume set,
- Add physical drive ,
- Modify volume set,
- Modify RAID level/stripe size,
- Define pass-through Disk drives,
- Modify system function,
- Update firmware, and
- Designate drives as hot spares.

6.1 Start-up McRAID Storage Manager

With the McRAID storage manager, you can locally manage a system containing a external RAID adapter that has Windows,

WEB BROWSER-BASED CONFIGURATION


Linux or more and a supported browser. A locally managed system requires all of the following components:

- A supported web browser, which should already be installed on the system.
- Install ArchHttp proxy server on the SATA RAID system. (Refer to Chapter 5, Archhttp Proxy Server Installation)
- Remote and managed systems must have a TCP/IP connection.

• Start-up McRAID Storage Manager from Windows Local Administration


Screen captures in this section are taken from a Windows XP installation. If you are running another version of Windows, your screens may look different, but the ArchHttp proxy server installation is essentially the same.

1. To start the McRAID storage manager for browser-based management, selecting "Controller#01(PCI)" and then click the "Start" button.



The "Enter Network Password" dialog screen appears, type the user name and password. The external RAID adapter default user name is "**admin**" and the password is "**0000**". After entering the user name and password, press "Enter" to access the McRAID storage manager.

WEB BROWSER-BASED CONFIGURATION



● Start-up McRAID Storage Manager from Linux/ FreeBSD/Solaris/Mac Local Administration

To configure the external RAID adapter. You need to know its IP address. You can find the IP address assigned by the Archhttp proxy server installation: Binding IP:[X.X.X.X] for[Computer IP Address] and controller listen to port for [Port Number].

(1). Launch your McRAID storage manager by entering `http://[Computer IP Address]:[Port Number]` in the web browser.

(2). When connection is established, the "System Login" screen appears. The external RAID adapter default user name is "admin" and the Password is "0000"

● Start-up McRAID Storage Manager Through Ethernet port (Out-of-Band)

Areca now offers an alternative means of communication for the PCIe RAID controller – Web browser-based McRAID storage manager program. User can access the built-in configuration without needing system starting up running the ArchHttp proxy sever. The web browser-based McRAID storage manager program is an HTML-based application, which utilizes the browser installed on your remote system.

To ensure proper communications between the PCIe RAID controller and web browser-based McRAID storage manager, Please connect the RAID controller LAN port to any LAN switch port.

The adapty has embedded the TCP/IP & web browser-based RAID manager in the firmware. User can remote manage the RAID controller without adding any user specific software (platform independent) via standard web browsers directly connected to the 10/100 RJ45 LAN port.

WEB BROWSER-BASED CONFIGURATION


To configure RAID adapter on a remote machine, you need to know its IP address. The IP address will default show in McBIOS RAID manager of "Ethernet Configuration" or "System Information" option. Launch your firmware-embedded TCP/IP & web browser-based McRAID storage manager by entering `http://[IP Address]` in the web browser.

Note:

You can find controller Ethernet port IP address in McBIOS RAID manager "System Information" option.

6.2 McRAID Storage Manager

The McRAID storage manager start-up configuration screen displays the current configuration of your external RAID adapter. It displays the Raid Set List, Volume Set List, and Physical Disk List. The RAID set information, volume set information, and drive information can also be viewed by clicking on the "Raid Set Hierarchy" screen. The current configuration can also be viewed by clicking on "Raid Set Hierarchy" in the main menu.



Areca Technology Corporation

Raid Set Hierarchy

Raid Set	IDE Channels	Volume Set(Ch/Id/Lun)	Volume State	Capacity
Raid Set # 00	Ch01	ARC-1120-VOL#00 (0/0/0)	Normal	500.1GB
	Ch02			
Raid Set # 00	Ch05	ARC-1210-VOL#00 (0/0/0)	Normal	250.0GB

IDE Channels

Channel	Usage	Capacity	Model
Ch01	Raid Set # 00	250.1GB	WDC WD2500SD-01KCB0
Ch02	Raid Set # 00	250.1GB	WDC WD2500SD-01KCB0
Ch03	Raid Set # 00	250.1GB	WDC WD2500JD-22HBB0
Ch04	N.A.	N.A.	N.A.
Ch05	Raid Set # 00	250.1GB	WDC WD2500JD-22HBB0
Ch06	N.A.	N.A.	N.A.
Ch07	N.A.	N.A.	N.A.
Ch08	N.A.	N.A.	N.A.

To display RAID set information, move the mouse cursor to the desired RAID set number, then click it. The RAID set information will display. To display volume set information, move the mouse cursor to the desired volume set number, then click it. The volume set information will display. To display drive information, move the mouse cursor to the desired physical drive number, then click it. The drive information will display.

WEB BROWSER-BASED CONFIGURATION

6.3 Main Menu

The main menu shows all available functions, accessible by clicking on the appropriate link.

Individual Category	Description
Quick Function	Create a default configuration, which is based on the number of physical disks installed; it can modify the volume set Capacity, Raid Level, and Stripe Size.
RaidSet Functions	Create a customized RAID set.
VolumeSet Functions	Create customized volume sets and modify the existed volume sets parameter.
Physical Drives	Create pass through disks and modify the existing pass through drives parameters. Also provides the function to identify disk drives (blinking Fault LED).
System Controls	Setting the raid system configuration.
Information	Viewing the controller information. The "RaidSet Hierarchy" can be viewed through the "RaidSet Hierarchy" item.

6.4 Quick Function

Quick Function

Quick Create


RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

Quick Create Raid Volume Set

Total Number Of Disks

4

Select Raid Level

RAID 0

Maximum Capacity Allowed

100.1 GB

Select Capacity

100.1 GB

Greater Two TB Volume Support

No

Volume Initialization Mode

Foreground Init (Faster Completion)

Select Stripe Size

64 KBytes

☒ Confirm The Operation

Submit

Reset

Note:

In Quick Create, your volume set is automatically configured based on the number of disks in your system. Use the "Raid Set Functions" and "Volume Set Functions" if you prefer to customize your system.

WEB BROWSER-BASED CONFIGURATION

The number of physical drives in the external RAID adapter determines the RAID levels that can be implemented with the RAID set. You can create a RAID set associated with exactly one volume set. The user can change the RAID level, stripe size, and capacity. A hot spare option is also created depending upon the existing configuration.

Click the "Confirm The Operation" check box and click on the "Submit" button in the "Quick Create" screen, the RAID set and volume set will start to initialize.

Note:

If volume capacity exceeds 2TB, controller will show the "Greater Two TB Volume Support" sub-menu. Greater Two TB Volume Support option: No, 64bit LBA and For Windows.

For more details please download PDF file from **ftp://ftp.areca.com.tw/RaidCards/Documents/Manual_Spec/Over2TB_050721.zip**

6.5 RaidSet Functions

Use the "Raid Set Functions" and "Volume Set Functions" if you prefer to customize your system. Manual configuration can provide full control of the RAID set settings, but it will take longer to complete than the "Quick Volume/Raid Setup" configuration. Select the "Raid Set Functions" to manually configure the RAID set for the first time or delete and reconfigure existing RAID sets. (A RAID set is a group of disks containing one or more volume sets.)

6.5.1 Create Raid Set

To create a RAID set, click on the "Create Raid Set" link. A "Select The Drive For RAID Set" screen will be displayed showing the drive(s) connected to the current controller. Click on the selected physical drives within the current RAID set. The default RAID set name will always appear as "Raid Set. #".

Click the "Confirm The Operation" check box and click on the "Submit" button on the screen; the RAID set will start to initialize.

WEB BROWSER-BASED CONFIGURATION

Quick Function

RaidSet Functions


- Create Raid Set
- Delete Raid set
- Expand Raid Set
- Activate Raid Set
- Create Hot Spare
- Delete Hot Spare
- Rescue Raid Set

VolumeSet Functions

Physical Drives

System Controls

Information



Areca Technology Corporation

Select The IDE Drives For RAID Set

Select	Channel	Capacity	Model
<input checked="" type="checkbox"/>	IDE Ch05	80.0GB	ST380013AS
<input checked="" type="checkbox"/>	IDE Ch06	80.0GB	ST380013AS
<input checked="" type="checkbox"/>	IDE Ch07	80.0GB	ST380013AS
<input checked="" type="checkbox"/>	IDE Ch08	80.0GB	ST380013AS

Raid Set Name

☒ Confirm The Operation

6.5.2 Delete Raid Set

To delete a RAID set, click on the “Deleted Raid Set” link. The “Select The Raid Set To Delete” screen is displayed showing all existing RAID sets in the current controller. Click the RAID set number you which to delete in the select column on the delete screen. Click the “Confirm The Operation” check box and click on the “Submit” button in the screen to delete it.

Quick Function

RaidSet Functions


- Create Raid Set
- Delete Raid set
- Expand Raid Set
- Activate Raid Set
- Create Hot Spare
- Delete Hot Spare
- Rescue Raid Set

VolumeSet Functions

Physical Drives

System Controls

Information



Areca Technology Corporation

Select The Raid Set To Delete

Select	Raid Set Name	Member Disks	Capacity
<input checked="" type="checkbox"/>	Raid Set #00	4	320.1GB

☒ Confirm The Operation, VolumeSet In This RaidSet Will Also Be Deleted

6.5.3 Expand Raid Set

Instead of deleting a RAID set and recreating it with additional disk drives, the “Expand Raid Set” function allows the users to add disk drives to the RAID set that have already been created. To expand a RAID set:
Select the “Expand Raid Set” option. If there is an available disk, then the “Select SATA Drives For Raid Set Expansion” screen appears.
Select the target RAID set by clicking on the appropriate radio button. Select the target disk by clicking on the appropriate check box.
Press the **Yes** key to start the expansion on the RAID set.

WEB BROWSER-BASED CONFIGURATION

Quick Function

RaidSet Functions

Create Raid Set

Delete Raid set

Expand Raid Set

Activate Raid Set

Create Hot Spare

Delete Hot Spare


Rescue Raid Set

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

RAID Expansion on : Raid Set # 00 ; Member Disks : 1

Select	Channel	Capacity	Model
<input checked="" type="checkbox"/>	IDE Ch05	80.0GB	ST380013AS

☒ Confirm The Operation

SubmitReset

The new additional capacity can be utilized by one or more volume sets. The volume sets associated with this RAID set appear for you to have chance to modify RAID level or stripe size. Follow the instruction presented in the "Modify Volume Set " to modify the volume sets; operation system specific utilities may be required to expand operating system partitions.

Note:

1. Once the "Expand Raid Set" process has started, user can not stop it. The process must be completed.
2. If a disk drive fails during raid set expansion and a hot spare is available, an auto rebuild operation will occur after the RAID set expansion completes.

6.5.4 Activate Incomplete Raid Set

If one of the disk drives is removed in power off state, the RAID set state will change to "Incomplete State". If the user wants to continue to use the external RAID adapter, the user can use the "Activate Raid Set" option to active the RAID set. After the user completes this function, the RAID set state will change to "De-graded Mode".

Quick Function

RaidSet Functions

Create Raid Set

Delete Raid set

Expand Raid Set

Activate Raid Set

Create Hot Spare

Delete Hot Spare


Rescue Raid Set

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

Select The Raid Set To Activate

Select	Raid Set Name	Member Disks	Capacity
<input checked="" type="radio"/>	Raid Set # 00	2	160.1GB
<input type="radio"/>	Raid Set # 01	2	160.1GB

SubmitReset

WEB BROWSER-BASED CONFIGURATION

To activate the incomplete the RAID set, click on the "Activate Raid Set" link. A "Select The RAID SET To Activate" screen is displayed showing all RAID sets existing on the current controller. Click the RAID set number to activate in the select column. Click on the "Submit" button on the screen to activate the RAID set that had a disk removed (or failed) in the power off state. The external RAID adapter will continue to work in degraded mode.

6.5.5 Create Hot Spare

When you choose the "Create Hot Spare" option in the "Raid Set Functions", all unused physical devices connected to the current controller appear. Select the target disk by clicking on the appropriate check box. Click the "Confirm The Operation" check box and click the "Submit" button in the screen to create the hot spares.

The "Create Hot Spare" option gives you the ability to define a global hot spare.

Quick Function

RaidSet Functions

Create Raid Set

Delete Raid Set

Expand Raid Set

Activate Raid Set

Create Hot Spare

Delete Hot Spare


Rescue Raid Set

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

Select The IDE Drives For Hot Spare

Select	Channel	Capacity	Model
<input checked="" type="checkbox"/>	IDE Ch07	30.0GB	ST380013AS
<input type="checkbox"/>	IDE Ch08	30.0GB	ST380013AS

☒ Confirm The Operation

SubmitReset

6.5.6 Delete Hot Spare

Select the target Hot Spare disk to be deleted by clicking on the appropriate check box.


Click the "Confirm The Operation" check box and click the "Submit" button on the screen to delete the hot spares.

6.5.7 Rescue Raid Set

When the system is powered off in the RAID set update/creation period, it possibly could disappear due to this abnormal condition. The "RESCUE" function can recover the missing RAID set informa-

WEB BROWSER-BASED CONFIGURATION

tion. The RAID controller uses the time as the RAID set signature. The RAID set may have different time after the RAID set is recovered. The "SIGANT" function can regenerate the signature for the RAID set.



Quick Function

- [RAIDSet Functions](#)
 - Create Raid Set
 - Delete Raid set
 - Expand Raid Set
 - Activate Raid Set
 - Create Hot Spare
 - Delete Hot Spare
 - Rescue Raid Set
- [VolumeSet Functions](#)
- [Physical Drives](#)
- [System Controls](#)
- [Information](#)

Areca Technology Corporation

Try To Rescue Missing RAIDSET
Enter 'RESCUE' To Try To Recover Missing RaidSet
Enter 'SIGANT' To Regenerate RaidSet Signature If RaidSet Is Recovered

☐ **Confirm The Operation**

6.5.8 Offline Raid Set

This function is for customer being able to unmount and remount a multi-disk volume. All Hdds of the selected RAID set will be put into offline state, spun down and fault LED in fast blinking mode. User can remove those Hdds and insert new Hdds on those empty slots without needing power down the controller.

6.6 Volume Set Functions

A volume set is seen by the host system as a single logical device. It is organized in a RAID level with one or more physical disks. RAID level refers to the level of data performance and protection of a volume set. A volume set capacity can consume all or a portion of the disk capacity available in a RAID set. Multiple volume sets can exist on a group of disks in a RAID set. Additional volume sets created in a specified RAID set will reside on all the physical disks in the RAID set. Thus each volume set on the RAID set will have its data spread evenly across all the disks in the RAID set.

6.6.1 Create Volume Set

1. Volume sets of different RAID levels may coexist on the same RAID set.
2. Up to 16 volume sets can be created by the external RAID adapter.
3. The maximum addressable size of a single volume set is not limited to 2 TB because the controller is capable of 64-bit mode.

WEB BROWSER-BASED CONFIGURATION

However, the operating system itself may not be capable of addressing more than 2 TB. See the Areca website for details.

To create a volume set on a RAID set, move the cursor bar to the main menu and click on the "Create Volume Set" link. This "Select The Raid Set To Create On It" screen will show all RAID set numbers. Click the RAID set number that to be used and then click the "Submit" button.

The "Enter Volume Attributeid Set=xx" option allows users to select the volume name, capacity, RAID level, stripe size, SCSI ID/LUN, cache mode, and tag queuing.

Areca Technology Corporation

Enter Volume Attribute On Raid Set # 00

Volume Name	Volume Set #00
Member Disks	4
Volume Raid Level	Raid 5
Max Capacity Allowed	100.1 GB
Select Volume Capacity	100.1 GB
Greater Two TB Volume Support	No
Volume Initialization Mode	Fastwrite (For Faster Completion)
Volume Stripe Size	64 KByte
Volume Cache Mode	Write Back
Tagged Command Queuing	Enabled
SCSI Channel/SCSI ID/SCSI LUN	0 0 0

☒ Confirm The Operation

Submit Reset

- **Volume Name**

The default volume name will always appear as "Volume Set. #". You can rename the volume set providing it does not exceed the 15 characters limit.

- **Raid Level**

Set the RAID level for the volume set. Highlight the desired RAID Level and press **Enter** key. The available RAID levels for the current volume set are displayed. Select a RAID level and press "Enter" to confirm.

- **Capacity**

The maximum volume size is the default initial setting. Enter the appropriate volume size to fit your application.

- **Greater Two TB Volume Support**

If volume capacity exceeds 2TB, controller will show the "Greater Two TB Volume Support" sub-menu. Greater Two TB Volume Supports: No, 64bit LBA and For Windows options.

WEB BROWSER-BASED CONFIGURATION

For more details please download PDF file from ftp://ftp.areca.com.tw/RaidCards/Documents/Manual_Spec/Over2TB_050721.zip

● Initialization Mode

Press **Enter** key to define "Background Initialization", "Foreground Initialization" or "No Init (To Rescue Volume)". When "Background Initialization", the initialization proceeds as a background task, the volume set is fully accessible for system reads and writes. The operating system can instantly access to the newly created arrays without requiring a reboot and waiting the initialization complete. When "Foreground Initialization", the initialization proceeds must be completed before the volume set ready for system accesses. There is no initialization happened when you select "No Init" option. "No Init" is for customer to rescue volume without losing data in the disk.

● Stripe Size

This parameter sets the size of the stripe written to each disk in a RAID level 0, 1, 10, 5 or 6 logical drive. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB.

A larger stripe size produces better read performance, especially if your computer does mostly sequential reads. However, if you are sure that your computer does random reads more often, select a smaller stripe size.

Note: RAID level 3 can't modify cache stripe size.

● Cache Mode

The external RAID adapter supports "Write Through" and "Write Back" cache.

● SCSI Channel/SCSI ID/SCSI Lun

SCSI Channel: The external RAID adapter function is simulated as a SCSI RAID controller. The host bus is represented as a SCSI channel. Choose the SCSI Channel.

SCSI ID: Each SCSI device attached to the SCSI card, as well as the card itself, must be assigned a unique SCSI ID number. A SCSI channel can connect up to 15 devices. The external RAID adapter is a large SCSI device. Assign an ID from a list of SCSI IDs.

WEB BROWSER-BASED CONFIGURATION


SCSI LUN: Each SCSI ID can support up to 8 LUNs. Most External RAID adapters treat each LUN like a SATA disk.

● Tag Queuing

The Enabled option is useful for enhancing overall system performance under multi-tasking operating systems. The Command Tag (Drive Channel) function controls the SCSI command tag queuing support for each drive channel. This function should normally remain enabled. Disable this function only when using older SATA drives that do not support command tag queuing.

6.6.2 Delete Volume Set

To delete a volume set from RAID set, move the cursor bar to the main menu and click on the "Delete Volume Set" link. The "Select The Raid Set To Delete" screen will show all RAID set numbers. Click a RAID set number and the "Confirm The Operation" check box and then click the "Submit" button to show all volume set items in the selected RAID set. Click a volume set number and the "Confirm The Operation" check box and then click the "Submit" button to delete the volume set.



Areca Technology Corporation

Select The Volume Set To Delete

Select	Volume Set Name	On Raid Set	Capacity
<input type="radio"/>	Volume Set # 00	Raid Set # 00	160.0GB

☒ Confirm The Operation

6.6.3 Modify Volume Set

To modify a volume set from a RAID set:

- (1). Click on the "Modify Volume Set" link.
- (2). Click the volume set check box from the list that you wish to modify. Click the "Submit" button. The following screen appears. Use this option to modify the volume set configuration. To modify volume set attributes, move the cursor bar to the volume set attribute menu and click it. The "Enter The Volume Attribute" screen appears. Move the cursor to an attribute item and then click the attribute to modify the value. After you complete the modifica-

WEB BROWSER-BASED CONFIGURATION

tion, click the "Confirm The Operation" check box and click the "Submit" button to complete the action. The user can modify all values except capacity.

6.6.3.1 Volume Growth

Use "Expand RAID Set" function to add disk to a RAID set. The additional capacity can be used to enlarge the last volume set size or to create another volume set. The "Modify Volume Set" function can support the "Volume Modification" function. To expand the last volume set capacity, move the cursor bar to the "Capacity" item and entry the capacity size. When finished the above action, press the **ESC** key and select the **Yes** option to complete the action. The last volume set starts to expand its capacity.

To expand an existing volume noticed:

- Only the last volume can expand capacity.
- When expand volume capacity, you can't modify stripe size or modify RAID level simultaneously.
- You can expand volume capacity, but can't reduce volume capacity size.
- After volume expansion, the volume capacity can't be decreased.

For greater 2TB expansion:

- If your system installed in the volume, don't expand the volume capacity greater 2TB, currently OS can't support boot up from a greater 2TB capacity device.
- Expand over 2TB used LBA64 mode. Please make sure your OS supports LBA64 before expand it.

6.6.3.2 Volume Set Migration

Migrating occurs when a volume set is migrating from one RAID level to another, when a volume set strip size changes, or when a disk is added to a RAID set. Migration status is displayed in the volume state area of the "Volume Set Information" screen.

6.6.4 Check Volume Set

Quick Function


RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

Raid Set Hierarchy

Raid Set	IDE Channels	Volume Set(Ch Id/Lun)	Volume State	Capacity
Raid Set # 00	Ch05	Volume Set # 00 (0/0/0)	Migration(10.5%)	160.0GB
	Ch06			
	Ch07			
	Ch08			

IDE Channels

Channel	Usage	Capacity	Model
Ch01	N.A.	N.A.	N.A.
Ch02	N.A.	N.A.	N.A.
Ch03	N.A.	N.A.	N.A.
Ch04	N.A.	N.A.	N.A.
Ch05	Raid Set # 00	80.0GB	ST380013AS
Ch06	Raid Set # 00	80.0GB	ST380013AS
Ch07	Raid Set # 00	80.0GB	ST380013AS
Ch08	Raid Set # 00	80.0GB	ST380013AS

To check a volume set from a RAID set:

Quick Function


RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

Select The Volume Set To Be Checked

Select	Volume Set Name	On Raid Set	Capacity
<input type="radio"/>	Volume Set # 00	Raid Set # 00	160.0GB

☒ Confirm The Operation

Submit

Reset

- (1). Click on the "Check Volume Set" link.

(2). Click on the volume set from the list that you wish to check. Tick on "Confirm The Operation" and click on the "Submit" button. Use this option to verify the correctness of the redundant data in a volume set. For example, in a system with dedicated parity, volume set check means computing the parity of the data disk drives and comparing the results to the contents of the dedicated parity disk drive. The checking percentage can also be viewed by clicking on "RaidSet Hierarchy" in the main menu.

6.6.5 Stop VolumeSet Check

Use this option to stop the “Check Volume Set function”.

Quick Function


RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

Do You Want To Stop All Volume Consistency Checking?

☒ Confirm The Operation

6.7 Physical Drive

Choose this option to select a physical disk from the main menu and then perform the operations listed below.

6.7.1 Create Pass Through Disk

To create pass through disk, move the mouse cursor to the main menu and click on the “Create Pass Through” link. The “Select the IDE Drive For Pass Through” screen appears. A pass through disk is not controlled by the external RAID adapter firmware, it cannot be a part of a volume set. The disk is available to the operating system as an individual disk. It is typically used on a system where the operating system is on a disk not controlled by the RAID firmware. The user can also select the Cache Mode, Tagged Command Queuing, SCSI channel/SCSI_ID/SCSI_LUN for this pass through disk.

Quick Function


RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

Information

Areca Technology Corporation

Select the IDE drive For Pass Through

Select	Channel	Capacity	Model
<input checked="" type="radio"/>	IDE Ch06	80.0GB	ST380013AS
<input type="radio"/>	IDE Ch07	80.0GB	ST380013AS
<input type="radio"/>	IDE Ch08	80.0GB	ST380013AS

Enter Pass Through Disk Attribute

Volume Cache Mode

Tagged Command Queuing

SCSI Channel:SCSI_ID:SCSI_Lun

☒ Confirm The Operation

6.7.2 Modify Pass Through Disk

Use this option to modify the "Pass Through Disk Attribute". The user can modify the Cache Mode, Tagged Command Queuing, and SCSI channel/ID/LUN on an existing pass through disk.

To modify the pass through drive attribute from the pass through drive pool, move the mouse cursor bar and click on the "Modify Pass Through" link. The "Select The Pass Through Disk For Modification" screen appears mark the checkbox for the pass through disk from the pass through drive pool and click on the "Submit" button to select drive.

When the "Enter Pass Through Disk Attribute" screen appears, modify the drive attribute values, as you want.

After you complete the selection, mark the check box for "Confirm The Operation" and click on the "Submit" button to complete the selection action.

The screenshot shows the 'Enter Pass Through Disk Attribute' web interface. On the left is a navigation menu with options: Quick Function, RaidSet Functions, VolumeSet Functions, Physical Drives (with sub-options: Create Pass Through, Modify Pass Through, Delete Pass Through, Identify Drive), System Controls, and Information. The main content area has the Areca Technology Corporation logo and title. Below is a form titled 'Enter Pass Through Disk Attribute' with a text field containing 'Ch06 80.0GB ST380013AS'. There are three rows of attributes: 'Volume Cache Mode' with a 'Write Back' dropdown, 'Tagged Command Queuing' with an 'Enabled' dropdown, and 'SCSI Channel/SCSI_ID/SCSI_Lun' with three numeric input fields (0, 0, 0). At the bottom, there is a 'Confirm The Operation' checkbox and 'Submit' and 'Reset' buttons.

6.7.3 Delete Pass Through Disk

To delete a pass through drive from the pass through drive pool, move the mouse cursor bar to the main menus and click the "Delete Pass Through" link.

After you complete the selection, mark the check box for "Confirm The Operation" and click the "Submit" button to complete the delete action.

The screenshot shows the 'Select The Pass Through Disk To Delete' web interface. It features the same navigation menu as the previous screen. The main content area has the Areca Technology Corporation logo and title. Below is a form titled 'Select The Pass Through Disk To Delete' with a table listing available disks. The table has columns: Select, Channel, Capacity, and Model. One row is visible: a radio button, IDE Ch06, 80.0GB, and ST380013AS. At the bottom, there is a 'Confirm The Operation' checkbox and 'Submit' and 'Reset' buttons.

WEB BROWSER-BASED CONFIGURATION

6.7.4 Identify Selected Drive

To prevent removal of the wrong drive, the selected fault LED will blink so as to physically locate the intended disk when "Identify Selected Drive" is selected.

To identify the selected drive from the drives pool, click "Identify Selected Drive". The "Select The IDE Device For Identification" screen appears mark the check box for the SATA device from the drive pool. After completing the selection, click on the "Submit" button to identify selected drive.

Select	Channel	Capacity	Model
<input checked="" type="radio"/>	IDE CH05	80.0GB	ST3300013AS
<input type="radio"/>	IDE CH06	80.0GB	ST3300013AS
<input type="radio"/>	IDE CH07	80.0GB	ST3300013AS
<input type="radio"/>	IDE CH08	80.0GB	ST3300013AS

6.8 System Controls

6.8.1 System Config

To set the RAID system configuration, move the cursor to the main menu and click the "System Controls" link. The "System Controls" will show all items, then select the desired function.

System Configurations	
System Beeper Setting	Enabled
Background Task Priority	Low(20%)
JBOD/RAID Configuration	JBOD
Max SATA Mode Supported	SATA300+NCQ
HDD Read Ahead Cache	Enabled
Volume Data Read Ahead	Normal
Empty HDD Slot LED	ON
HDD SMART Status Polling	Disabled
Auto Activate Incomplete Raid	Disabled
Disk Write Cache Mode	Auto
Disk Capacity Truncation Mode	Multiples Of 10G

WEB BROWSER-BASED CONFIGURATION

- **System Beeper Setting**

The "System Beeper Setting" function item is used to "Disable" or "Enable" the external RAID adapter alarm tone generator.

- **Background Task Priority**

The 'Background Task Priority' is a relative indication of how much time the controller devotes to a rebuild operation. The External RAID adapter allows the user to choose the rebuild priority (UltraLow, Low, Normal, High) to balance volume set access and rebuild tasks appropriately. For high array performance, specify a "Low" value.

- **JBOD/RAID Configuration**

JBOD is an acronym for "Just a Bunch Of Disk". A group of hard disks in a RAID controllers are not set up as any type of RAID configuration. All drives are available to the operating system as an individual disk. JBOD does not provide data redundancy. User needs to delete the RAID set, when you want to change the option from the RAID to the JBOD function.

- **Maximun SATA Supported**

The external RAID adapter can support up to SATA II, which runs up to 300MB/s. NCQ is a command protocol in Serial ATA that can only be implemented on native Serial ATA hard drives. It allows multiple commands to be outstanding within a drive at the same time. Drives that support NCQ have an internal queue where outstanding commands can be dynamically rescheduled or re-ordered, along with the necessary tracking mechanisms for outstanding and completed portions of the workload. The RAID adapter allows user to choose the SATA mode (slowest to fastest): SATA150, SATA150+NCQ, SATA300, SATA300+NCQ.

- **HDD Read Ahead Cache**

Allow Read Ahead (Default: Enabled)—When Enabled, the drive's read ahead cache algorithm is used, providing maximum performance under most circumstances.

- **Volume Data Read Ahead**

The Read data ahead parameter specifies the adapter firmware algorithms which process the Read Ahead data blocks from the disk. The Read Ahead parameter is normal by default. To

WEB BROWSER-BASED CONFIGURATION

modify the value, you must set it from the command line using the Read Ahead option. The default normal option satisfies the performance requirements for a typical volume. The disabled value implies no read ahead. The most efficient value for the controllers depends on your application. Aggressive read ahead is optimal for sequential access but it degrades random access.

● **Stagger Power on Control**

In a PC system with only one or two drives, the power is able to supply enough power to spin up both drives simultaneously. But in systems with more than two drives, the startup current from spinning up the drives all at once can overload the power supply, causing damage to the power supply, disk drives and other system components. This damage can be avoided by allowing the host to stagger the spin-up of the drives. New SATA drives have supported stagger spin-up capabilities to boost reliability. Staggered spin-up is a very useful feature for managing multiple disk drives in a storage subsystem. It gives the host the ability to spin up the disk drives sequentially or in groups, allowing the drives to come ready at the optimum time without straining the system power supply. Staggering drive spin-up in a multiple drive environment also avoids the extra cost of a power supply designed to meet short-term startup power demand as well as steady state conditions. External RAID adapter has included the option for customer to select the disk drives sequentially stagger power up value. The values can be selected from 0.4s to 6s per step which powers up one drive.

● **Empty HDD Slot LED**

The firmware has added the "Empty HDD Slot LED" option to setup the fault LED light "ON" or "OFF" when there is no HDD installed. When each slot has a power LED for the HDD installed identify, user can set this option to "OFF". Choose option "ON", the external RAID adapter will light the fault LED; if no HDD installed.

● **HDD SMART Status Polling**

An external RAID enclosure has the hardware monitor in the dedicated backplane that can report HDD temperature status to the controller. However, PCI type controllers do not use backplanes if the drives are internal to the main server chassis.

WEB BROWSER-BASED CONFIGURATION

sis. The type of enclosure cannot report the HDD temperature to the controller. For this reason, "HDD SMART Status Polling" function was added to enable scanning of the HDD temperature function. It is necessary to enable "HDD SMART Status Polling" function before SMART information is accessible. This function is disabled by default.

- **Disk Write Cache Mode**

A user can set the "Disk Write Cache Mode": Auto, Enabled, or Disabled.

- **Auto Activate Incomplete Raid**

When some of the disk drives are removed in power off state or boot up stage, the RAID set state will change to "Incomplete State". But if a user wants to automatically continue to work while the external RAID adapter is powered on, the user can set the "Auto Activate Incomplete Raid" option to enable. The RAID state will change to "Degraded Mode" while it powers on.

- **Disk Capacity Truncation Mode**

External RAID adapter use drive truncation so that drives from differing vendors are more likely to be able to be used as spares for each other. Drive truncation slightly decreases the usable capacity of a drive that is used in redundant units. The controller provides three truncation modes in the system configuration: "Multiples Of 10G", "Multiples Of 1G", and "No Truncation".

Multiples Of 10G: If you have 120 GB drives from different vendors; chances are that the capacity varies slightly. For example, one drive might be 123.5 GB, and the other 120 GB. "Multiples Of 10G" truncates the number under tens. This makes the same capacity for both of these drives so that one could replace the other.

Multiples Of 1G: If you have 123 GB drives from different vendors; chances are that the capacity varies slightly. For example, one drive might be 123.5 GB, and the other 123.4 GB. "Multiples Of 1G" truncates the fractional part. This makes the same capacity for both of these drives so that one could replace the other.

WEB BROWSER-BASED CONFIGURATION

No Truncation: It does not truncate the capacity.

6.8.2 Ethernet Configuration (ARC-1202)

Use this feature to set the controller Ethernet port configuration. A customer doesn't need to create a reserved space on the arrays before the Ethernet port and HTTP service are working. The firmware-embedded Web Browser-based RAID storage manager can access it from any standard internet browser or from any host computer either directly connected or via a LAN or WAN with no software or patches required.

DHCP (Dynamic Host Configuration Protocol) is a protocol that lets network administrators manage centrally and automate the assignment of IP (Internet Protocol) configurations on a computer network. When using the internet's set of protocols (TCP/IP), in order for a computer system to communicate to another computer system, it needs a unique IP address. Without DHCP, the IP address must be entered manually at each computer system. DHCP lets a network administrator supervise and distribute IP addresses from a central point. The purpose of DHCP is to provide the automatic (dynamic) allocation of IP client configurations for a specific time period (called a lease period) and to eliminate the work necessary to administer a large IP network.

To configure the RAID adapter Ethernet port, move the cursor bar to the main menu and click on the "System Controls" link. The "System Controls" menu will show all items. Move the cursor bar to the "EtherNet Config" item, then press "Enter" key to select the desired function.

ⓀQuick Function

Ⓚ RAID Set Functions

Ⓚ Volume Set Functions

Ⓚ Physical Drives

Ⓚ System Controls

System Config

Hold Power Management

EtherNet Config

Alert By Mail Config

SNMP Configuration

NTP Configuration

View Event/Note Register


Generate Test Event

Clear Event Buffer

Modify Password

Upgrade Firmware

Ⓚ Information



Areca Technology Corporation

Ether Net Configurations

DHCP Function

Enabled

Local IP Address (Used If DHCP Disabled)

192

168

1

100

Gateway IP Address (Used If DHCP Disabled)

192

168

1

1

Subnet Mask (Used If DHCP Disabled)

255

255

255

0

HTTP Port Number (7168-8191 Is Reserved)

80

Telnet Port Number (7168-8191 Is Reserved)

23

SMTP Port Number (7168-8191 Is Reserved)

25

Current IP Address

192.168.0.178

Current Gateway IP Address

192.168.0.1

Current Subnet Mask

255.255.255.0

Ether Net MAC Address

00 04 D9 70 00 C9

☐ Confirm The Operation

6.8.3 Alert by Mail Configuration (ARC-1202)

To configure the external RAID adapter e-mail function, move the cursor bar to the main menu and click on the "System Controls" link. The "System Controls" menu will show all items. Move the cursor bar to the "Alert By Mail Config" item, then select the desired function. This function can only be set via web-based configuration.

The firmware contains a SMTP manager monitoring all system events. Single or multiple user notifications can be sent via "Plain English" e-mails with no software required.

Quick Function

RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

System Config

RAID Power Management

EdtNet Config

Alert By Mail Config

SNMP Configuration

NTP Configuration

View Events/Status Report


Generate Test Event

Clear Event Buffer

Modify Password

Upgrade Firmware

Information

Areca Technology Corporation

SMTP Server Configuration

SMTP Server IP Address

Mail Address Configurations

Sender Name

Mail Address

Account

Password

MailTo Name1

Mail Address

MailTo Name2

Mail Address

MailTo Name3

Mail Address

MailTo Name4

Mail Address

Event Notification Configurations

☒ Disable Event Notification

No Event Notification Will Be Sent

☐ Urgent Error Notification

Send Only Urgent Event

☐ Serious Error Notification

Send Urgent And Serious Event

☐ Warning Error Notification

Send Urgent, Serious And Warning Event

☐ Information Notification

Send All Event

☐ Notification For No Event

Notify User If No Event Occurs Within 24 Hours

☒ Confirm The Operation

Submit

Reset


6.8.4 SNMP Configuration (ARC-1202)

To configure the RAID adapter SNMP function, click on the "System Controls" link. The "System Controls" menu will show available items. Select the "SNMP Configuration" item. This function can only set via web-based configuration.

The firmware SNMP agent manager monitors all system events and the SNMP function becomes functional with no agent software required.

116

WEB BROWSER-BASED CONFIGURATION



Areca Technology Corporation

SNMP Trap Configurations

SNMP Trap IP Address #1	0	0	0	0	Port#	162
SNMP Trap IP Address #2	0	0	0	0	Port#	162
SNMP Trap IP Address #3	0	0	0	0	Port#	162

SNMP System Configurations

Community	
sysContact.0	
sysName.0	
sysLocation.0	

SNMP Trap Notification Configurations

<input checked="" type="radio"/> Disable SNMP Trap	No SNMP Trap Will Be Sent
<input type="radio"/> Urgent Error Notification	Send Only Urgent Event
<input type="radio"/> Serious Error Notification	Send Urgent And Serious Event
<input type="radio"/> Warning Error Notification	Send Urgent, Serious And Warning Event
<input type="radio"/> Information Notification	Send All Event

☐ Confirm The Operation

- **SNMP Trap Configurations**

Enter the SNMP Trap IP Address.

- **SNMP System Configurations**

About community, please refer to Appendix C of SNMP community name. The system Contact, Name and Location that will be shown in the outgoing SNMP Trap.

- **SNMP Trap Notification Configurations**

Please refer to Appendix D of Event Notification Table.

6.8.5 NTP Configuration (ARC-1202)

The “Network Time Protocol (NTP)” is used to synchronize the time of a computer client or server to another server or reference time source, such as a radio or satellite receiver or modem. It provides accuracies typically within a millisecond on LANs and up to a few tens of milliseconds on WANs relative to Coordinated Universal Time (UTC) via a Global Positioning Service (GPS) receiver, for example:

WEB BROWSER-BASED CONFIGURATION

● NTP Sever Address

The most important factor in providing accurate, reliable time is the selection of NTP servers to be used in the configuration file. Typical NTP configurations utilize multiple redundant servers and diverse network paths in order to achieve high accuracy and reliability. Our NTP configuration supports two existing public NTP synchronization subnets.

● Time Zone

The "Time Zone" conveniently runs in the system tray and allows you to view the date and time in various locations around the world easily. You are also able to add your own personal locations to customize time zone the way you want with great ease and less hassle.

● Automatic Daylight Saving

The "Automatic Daylight Saving" will normally attempt to automatically adjust the system clock for daylight saving changes based on the computer time zone. This tweak allows you to disable the automatic adjustment.

@Quick Function

@RaidSet Functions

@VolumeSet Functions

@Physical Drives

System Controls

System Config

Hard Power Management

EtherNet Config

Alert By Mail Config

SNMP Configuration

NTP Configuration


Generate Test Event

Clear Event Buffer

Modify Password

Upgrade Firmware

@Information



Areca Technology Corporation

NTP Server Configurations

NTP Server IP Address #10000

NTP Server IP Address #20000

Time Zone Configuration

Time Zone : (GMT-12:00)International Date Line West

Automatic Daylight Saving : Enabled

Current Time : 2005/12/14 15:47

NTP Server Not Set

Confirm The Operation

SubmitReset

Note:

NTP feature works through onboard Ethernet port. So you must make sure that you have already connected it.

WEB BROWSER-BASED CONFIGURATION

6.8.6 View Events/Mute Beeper

To view the external RAID adapter's information, click on the "View Events/Mute Beeper" link. The external RAID adapter "System Events information" screen appears.

Choose this option to view the system events information: Timer, Device, Event type, Elapse Time and Errors. The RAID system does not have a built-in real time clock. The time information is the relative time from the external RAID adapter power on.

Quick Function

RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

System Config

EtherNet Config

Alert By Mail Config

SNMP Configuration

NTP Configuration

View Events/Mute Beeper

Generate Test Event

Clear Event Buffer

Modify Password

Upgrade Firmware

Information



Areca Technology Corporation

System Events Information

Time	Device	Event Type	Elapse Time	Errors
2005-12-14 15:25:51	ARC-1260-VOL#01	Complete Init	000:14:56	
2005-12-14 14:17:57	192.168.000.196	HTTP Log In		
2005-12-14 14:17:44	ARC-1260-VOL#01	Start Initialize		
2005-12-14 14:17:11	H/W Monitor	Raid Powered On		
2005-12-14 15:9:50	ARC-1260-VOL#01	Complete Init	000:04:59	
2005-12-14 14:12:12	192.168.000.196	HTTP Log In		
2005-12-14 14:11:41	ARC-1260-VOL#01	Start Initialize		
2005-12-14 14:8:39	H/W Monitor	Raid Powered On		
2005-12-14 14:8:9	ARC-1260-VOL#01	Complete Init	000:00:09	
2005-12-14 14:7:59	ARC-1260-VOL#01	Start Initialize		
2005-12-14 14:7:58	ARC-1260-VOL#01	Create Volume		
2005-12-14 14:7:20	RS232 Terminal	VT100 Log In		
2005-12-14 14:7:10	H/W Monitor	Raid Powered On		
2005-12-14 14:51:54	192.168.000.196	HTTP Log In		

6.8.7 Generate Test Event

This feature is used to generate events for testing purposes.

Quick Function

RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

System Config

EtherNet Config

Alert By Mail Config

SNMP Configuration

NTP Configuration

View Events/Mute Beeper


Generate Test Event

Clear Event Buffer

Modify Password

Upgrade Firmware

Information



Areca Technology Corporation

Do You Want To Generate Test Event?

☐ Confirm The Operation

Submit

Reset

WEB BROWSER-BASED CONFIGURATION

6.8.8 Clear Events Buffer

Use this feature to clear the entire events buffer information.




The screenshot shows the Areca Technology Corporation web interface. On the left is a navigation menu with the following items: Quick Function, RaidSet Functions, VolumeSet Functions, Physical Drives, System Controls, System Config, EtherNet Config, Alert By Mail Config, SNMP Configuration, NTP Configuration, View Events/Make Responder, Generate Test Event, Clear Event Buffer (highlighted in red), Modify Password, and Upgrade Firmware. The main content area displays a confirmation screen titled 'Do You Want To Clear The Event Buffer?'. It includes a checkbox labeled 'Confirm The Operation' and two buttons: 'Submit' and 'Reset'.

6.8.9 Modify Password

To set or change the external RAID adapter password, select “Modify Password” from the menu and click on the “Modify Password” link. The “Modify System Password” screen appears.

The manufacture default password is set to 0000. The password option allows user to set or clear the external RAID adapter’s password protection feature. Once the password has been set, the user can only monitor and configure the external RAID adapter by providing the correct password.

The password is used to protect the external RAID adapter from unauthorized entry. The controller will check the password only when entering the main menu from the initial screen. The external RAID adapter will automatically go back to the initial screen when it does not receive any command in 5 minutes. Do not use spaces when you enter the password, If spaces are used, it will lock out the user. To disable the password, leave the fields blank. Once the user confirms the operation and clicks the “Submit” button, the existing password will be cleared. After which, no password checking will occur when entering the main menu from the starting screen.



The screenshot shows the 'Modify System Password' screen in the Areca Technology Corporation web interface. The left navigation menu is identical to the previous screenshot, with 'Modify Password' highlighted in red. The main content area contains a form with four input fields: 'Enter Original Password', 'Enter New Password', 'Re-Enter New Password', and a checkbox labeled 'Confirm The Operation'. Each of the first three fields has a masked password '0000' displayed. Below the form are 'Submit' and 'Reset' buttons.

6.8.10 Update Firmware

Please refer to the appendix A Upgrading Flash ROM Update Process.

Quick Function

RaidSet Functions

VolumeSet Functions

Physical Drives

System Controls

System Config

EtherNet Config

Alert By Mail Config

SNMP Configuration

NTP Configuration

View Events/Mute Beacon

Generate Test Event

Clear Event Buffer

Modify Password

Upgrade Firmware

Information



Areca Technology Corporation

Upgrade The Raid System Firmware Or Boot Rom

Enter The BootRom Or Firmware File Name

☐ Confirm The Operation

6.9 Information

6.9.1 RaidSet Hierarchy

Use this feature to view the external RAID adapter current RAID set, current volume set and physical disk configuration. Please reference this chapter “Configuring Raid Sets and Volume Sets”.

Quick Function

RaidSet Functions

VolumeSet Functions

Physical Drives


System Controls

Information

RaidSet Hierarchy

System Information

Hardware Monitor



Areca Technology Corporation

Raid Set Hierarchy

Raid Set	IDE Channels	Volume Set(ChId/Lun)	Volume State	Capacity
Raid Set # 00	Ch01	Volume Set # 00 (0/0/0)	Normal	100.0GB
	Ch04	Volume Set # 01 (0/0/0)	Normal	60.0GB
	Ch03	Volume Set # 02 (0/1/0)	Normal	100.0GB
	Ch02			
	Ch05			
	Ch06			
	Ch07			
	Ch08			
	Ch09			
	Ch10			
	Ch12			
	Ch11			
	Ch13			
	Ch14			
	Ch15			
	Ch16			


IDE Channels

Channel	Usage	Capacity	Model
Ch01	Raid Set # 00	82.0GB	Master 6Y080M0
Ch02	Raid Set # 00	82.0GB	Master 6Y080M0
Ch03	Raid Set # 00	82.0GB	Master 6Y080M0
Ch04	Raid Set # 00	82.0GB	Master 6Y080M0
Ch05	Raid Set # 00	82.0GB	Master 6Y080M0
Ch06	Raid Set # 00	82.0GB	Master 6Y080M0
Ch07	Raid Set # 00	82.0GB	Master 6Y080M0

6.9.2 System Information

To view the external RAID adapter's information, move the mouse cursor to the main menu and click on the "System Information" link. The "Raid Subsystem Information" screen appears.

Use this feature to view the external RAID adapter's information. The controller name, firmware version, serial number, main processor, CPU data/instruction cache size and system memory size/speed appear in this screen.



Raid Subsystem Information	
Controller Name	ARC-1220
Firmware Version	V1.35 2004-12-31
BOOT ROM Version	V1.35 2004-12-31
Serial Number	D0112ARC1200B01
Main Processor	500MHz IOP332
CPU DCache Size	32KBytes
CPU ICache Size	32KBytes / Write Back
System Memory	256MB / 333MHz
Current IP Address	192.168.0.114

6.9.3 Hardware Monitor

To view the RAID controller's hardware monitor information, move the mouse cursor to the main menu and click the "Hardware Monitor" link. The "Hardware Monitor Information" screen appears.

The "Hardware Monitor Information" provides the temperature, and fan speed (I/O Processor fan) of the External RAID adapter.

The ARC-1212x/1222x card interface lists two temperatures; one for the I/O processor and the other one for the controller. The I/O processor temperature is a new feature which detects by a thermal sensor under the IOP348. The processor safe range is 90 Celsius degree and the controller safe range is 70 Celsius degree. If any sensor detects over the safe ranges on these temperatures, you will get a warning event.

WEB BROWSER-BASED CONFIGURATION

Quick Function

ReadSet Functions

VolumeSet Functions

Physical Drives


System Controls

Information

ReadSet Hierarchy

System Information

Hardware Monitor

Areca Technology Corporation

Hardware Monitor Information

Fan Speed	2178 RPM
Battery Status	Not Installed
Hd@#1 Temperature	30 °C
Hd@#2 Temperature	28 °C
Hd@#3 Temperature	30 °C
Hd@#4 Temperature	35 °C
Hd@#5 Temperature	35 °C
Hd@#6 Temperature	34 °C
Hd@#7 Temperature	31 °C
Hd@#8 Temperature	35 °C
Hd@#9 Temperature	31 °C
Hd@#10 Temperature	35 °C
Hd@#11 Temperature	37 °C
Hd@#12 Temperature	39 °C
Hd@#13 Temperature	37 °C
Hd@#14 Temperature	30 °C
Hd@#15 Temperature	30 °C
Hd@#16 Temperature	33 °C

APPENDIX

Appendix A

Upgrading Flash ROM Update Process

Since the external RAID adapter features flash firmware, it is not necessary to change the hardware flash chip in order to upgrade the RAID firmware. The user can simply re-program the old firmware through the In-Band PCI-X/PCIe bus or Out-of-Band Ethernet port McRAID storage manager. New releases of the firmware are available in the form of a DOS file on the shipped CD or Areca website. The files available at the FTP site for each model contain the following files in each version:

ARCXXXXNNNN.BIN Software Binary Code (where "XXXX" refers to the model name and "NNNN" refers to the software code type)

ARCXXXXBIOS.BIN :→ PCI card BIOS for system board using

ARCXXXXBOOT.BIN :→ RAID controller hardware initialization

ARCXXXXFIRM.BIN :→ RAID kernel program

ARCXXXXMBR0.BIN:→ Master Boot Record for supporting Dual Flash Image in the SATA II RAID controller

ITPFXXXX.BIN:→ Intel 348 SAS controller transport layer microcode


README.TXT contains the history information of the software code change in the main directory. Read this file first to make sure you are upgrading to the proper binary file. Select the right file for the upgrade. Normally, user upgrades the ARCXXXXBIOS.BIN for system M/B compatibility and ARCXXXXFIRM.BIN for RAID function upgrades.

Note:

Please update all Binary Code (BIOS, BOOT and FIRM) before you reboot system. Otherwise, a mixed firmware package may hang the controller.

Upgrading Firmware Through McRAID Storage Manager

Get the new version firmware for your external RAID adapter. For example, download the bin file from your OEM's web site onto the C: drive



1. To upgrade the RAID controller firmware, move the mouse cursor to "Upgrade Firmware" link. The "Upgrade The Raid System Firmware" screen appears.
2. Click "Browse". Look in the location to which the firmware upgrade software was downloaded. Select the file name and click "Open". All files (BIOS, BOOT, FIRM and MBR0) can be updated through this function.
3. Click "Confirm The Operation" and press the "Submit" button.
4. The web browser begins to download the firmware binary to the controller and start to update the flash ROM.
5. After the firmware upgrade is complete, a bar indicator will show "Firmware Has Been Updated Successfully"
6. After the new firmware has completed downloading, find a chance to restart the controller/computer for the new firmware to take effect.

The web browser-based McRAID storage manager can be accessed through the In-Band PCI-X/PCIe bus or Out-of-Band LAN port. The In-Band method uses the ArcHttp proxy server to launch the McRAID storage manager. The Out-of-Band method allows local or remote to access the McRAID storage manager from any standard internet browser via a LAN or WAN with no software or patches required.

Controller with onboard LAN port, you can directly plug an Ethernet cable to the controller LAN port, then enter the McBIOS RAID manager to configure the network setting. After network setting configured and saved, you can find the current IP address in the "System Information" page.

APPENDIX

From a remote PC, you can directly open a web browser and enter the IP address. Then enter user name and password to login and start your management. You can find the firmware update feature in the browser console: "System Controls" option.

Upgrading Firmware Through nflash DOS Utility

Areca now offers an alternative means communication for the external RAID adapter – Upgrade the all files (BIOS, BOOT, FIRM and MBR0) without necessary system starting up to running the ArchHttp proxy server. The nflash utility program is a DOS application, which runs in the DOS operating system. Be sure of ensuring properly to communicate between external RAID adapter and nflash DOS utility. Please make a bootable DOS floppy diskette or UBS devices from other Windows operating system and boot up the system from those bootable devices.

● Starting the nflash Utility

You do not need to short any jumper cap on running nflash utility. The nflash utility provides an on-line table of contents, brief descriptions of the help sub-commands. The nflash utility put on the <CD-ROM>\Firmware directory. You can run the <nflash> to get more detailed information about the command usage. Typical output looks as below:

```
A:\nflash
Raid Controller Flash Utility
V1.11 2007-11-8
Command Usage:
NFLASH FileName
NFLASH FileName /cn --> n=0,1,2,3 write binary to controller#0
FileName May Be ARC1210FIRM.BIN or ARC1210*
For ARC1210* Will Expand To ARC1210BOOT /FIRM/BIOS.BIN

A:\>nflash arc1210FIRM.BIN
Raid Controller Flash Utility
V1.11 2007-11-8
NODEL : ARC-1210
MEM FE620000 FE7FF000
File ARC1210FIRM.BIN : >>*** => Flash OK
```

Note:

Areca SAS and SATA II RAID controller firmware version 1.43 date: Feb 2007 and later has supported the ATA-8 spec for HDD microcode download, allowing customer using nflash DOS utility or web browser to upgrade ATA-8 spec for microcode download supported HDD's firmware connected with Areca's entire family RAID controllers without necessary removing any single drive and upgrade. Areca has provided one utility for customer to make the ATA-8 spec for microcode download drive's firmware for readable by Areca firmware.


APPENDIX

Appendix B

Battery Backup Module (ARC6120-BAT-xxx)

The external RAID adapter operates using cache memory. The Battery Backup Module is an add-on module that provides power to the external RAID adapter cache memory in the event of a power failure. The Battery Backup Module monitors the write back cache on the external RAID adapter, and provides power to the cache memory if it contains data not yet written to the hard drives when power failure occurs.

BBM Components




Status of BBM

- D13 (Green) : lights when BBM activated
- D14 (Red) : lights when BBM charging
- D15 (Green) : lights when BBM normal

Installation

1. Make sure all power to the system is disconnected.
2. Connector J1 is available for the optional battery backup module. Connect the BBM cable to the 12-pin battery connector on the controller.
3. Integrators may provide pre-drilled holes in their cabinet for securing the BBM using its three mounting positions.



Battery Backup Capacity

Battery backup capacity is defined as the maximum duration of a power failure for which data in the cache memory can be maintained by the battery. The BBM's backup capacity varied with the memory chips that installed on the external RAID adapter.

Operation

1. Battery conditioning is automatic. There are no manual procedures for battery conditioning or preconditioning to be performed by the user.
2. In order to make sure of all the capacity is available for your battery cells, allow the battery cell to be fully charged when installed for the first time. The first time charge of a battery cell takes about 24 hours to complete.

Changing the Battery Backup Module

At some point, the LI-ION battery will no longer accept a charge properly. LI-ION battery life expectancy is anywhere from approximately 1 to 5 years.

1. Shutdown the operating system properly. Make sure that cache memory has been flushed.
2. Disconnect the BBM cable from J2 on the RAID controller.
3. Disconnect the battery pack cable from JP2 on the BBM.

APPENDIX

4. Install a new battery pack and connect the new battery pack to JP2.
5. Connect the BBM to J2 on the external RAID adapter.
6. Disable the write-back function from the McBIOS or Utility.

Note:

Do not remove BBM while system is running.

Battery Functionality Test Procedure:

1. Writing amount of data into controller volume, about 5GB or bigger.
2. Waiting for few seconds, power failed system by remove the power cable
3. Check the battery status, make sure the D13 is bright light, and battery beeps every few seconds.
4. Power on system, and press Tab/F6 to login controller.
5. Check the controller event log, make sure the event shows controller boot up with power recovered.

BBM Specifications

Mechanical

- Module Dimension (W x H x D)
37.3 x 13 x 81.6 mm
- BBM Connector
2 * 6 box header

Environmental

- Operating Temperature
Temperature: 0° C to +40° C
- Humidity: 45-85%, non-condensing
- Storage Temperature
Temperature: -40° C to 60° C
- Humidity: 45-85%, non-condensing

Electrical

- Input Voltage
+3.6VDC
- On Board Battery Capacity
1100mAH (1*1100mAH)

Appendix C

SNMP Operation & Definition

Overview

The McRAID storage manager includes a firmware-embedded Simple Network Management Protocol (SNMP) agent and SNMP Extension Agent for the external RAID adapter. An SNMP-based management application (also known as an SNMP manager) can monitor the disk array. An example of An SNMP management application is Hewlett-Packard's Open View. The SNMP Extension Agent can be used to augment the external RAID adapter if you are already running an SNMP management application at your site.


SNMP Definition

SNMP, an IP-based protocol, has a set of commands for getting the status of target devices. The SNMP management platform is called the SNMP manager, and the managed devices have the SNMP agent loaded. Management data is organized in a hierarchical data structure called the Management Information Base (MIB). These MIBs are defined and sanctioned by various industry associations. The objective is for all vendors to create products in compliance with these MIBs so that inter-vendor interoperability can be achieved. If a vendor wishes to include additional device information that is not specified in a standard MIB, then that is usually done through MIB extensions.

APPENDIX

MIB Compilation and Definition File Creation

Before the manager application accesses the external RAID adapter, it is necessary to integrate the MIB into the management application's database of events and status indicator codes. This process is known as compiling the MIB into the application. This process is highly vendor-specific and should be well-covered in the User's Guide of your SNMP application. Ensure the compilation process successfully integrates the contents of the ARECARAID.MIB file into the traps database.




SNMP Installation

The installation of the SNMP manager is accomplished in several phases:

- Starting the firmware-embedded SNMP community configuration.
- Installing the SNMP Extension Agent on the server
- Installing the SNMP manager software on the client
- Placing a copy of the Management Information Base (MIB) in a directory which is accessible to the management application
- Compiling the MIB description file with the management application

Starting the SNMP Function Setting



The screenshot shows the Areca Technology Corporation web interface. On the left is a navigation menu with the following items: Quick Function, RAID Set Functions, Volume Set Functions, Physical Drives, System Controls (with sub-items: System Config, SNMP Configuration, View Events/Write Responder, Generate Test Event, Clear Event Buffer, Modify Password, Upgrade Firmware), and Information. The main content area is titled 'SNMP Community Configuration'. It features a 'Community' input field, a checkbox labeled 'Confirm The Operation', and 'Submit' and 'Reset' buttons.

● Community Name

Community name acts as a password to screen accesses to the SNMP agent of a particular network device. Type in the community names of the SNMP agent. Before access is granted to a request station, this station must incorporate a valid community name into its request; otherwise, the SNMP agent will deny access to the system.

Most network devices use “public” as default of their community names. This value is case-sensitive.

SNMP Extension Agent Installation for Windows

You must have the administrative level permission to install external RAID adapter software. This procedure assumes that the external RAID adapter hardware and Windows are both installed and operational in your system.


To enable the SNMP agent for Windows, configure Windows for TCP/IP and SNMP services. The Areca SNMP Extension Agent file is ARCSNMP.DLL.

Screen captures in this section are taken from a Windows XP installation. If you are running another version of Windows, your screens may look different, but the Areca SNMP Extension Agent installation is essentially the same.


1. Insert the external RAID adapter CD in the CD-ROM drive.

APPENDIX


2. Run the setup.exe file that resides at: <CD-ROM>\packages\windows\http\setup.exe on the CD-ROM. (If SNMP service was not installed, please install SNMP service first.)




3. Click on the "Setup.exe" file then the welcome screen appears.




4. Click the "Next" button and then the "Ready Install the Program" screen appears. Follow the on-screen prompts to complete Areca SNMP Extension Agent installation.



5. A Progress bar appears that measures the progress of the Areca SNMP Extension Agent setup. When this screen complete, you have completed the Areca SNMP Extension Agent setup.



6. After a successful installation, the "Installshield Wizard Completed" dialog box of the installation program is displayed. Click the "Finish" button to complete the installation.




Starting SNMP Trap Notification Configurations

To start "SNMP Trap Notification Configurations", There have two methods. First, double-click on the "Areca Raid Controller".



Second, you may also use the "Taskbar Start/programs/Areca Technology Corp/ArcSnmpConf" menus shown below.

APPENDIX




SNMP Community Configurations

Please refer to the community name in this appendix.

SNMP Trap Notification Configurations

The "Community Name" should be the same as firmware-embedded SNMP community. The "SNMP Trap Notification Configurations" include level 1: Serious, level 2: Error, level 3: Warning and level 4: Information. The level 4 covers notification events such as initialization of the controller and initiation of the rebuilding process; Level 3 includes events which require the issuance of warning messages; Level 2 covers notification events which once have happen; Level 1 is the highest level, and covers events the need immediate attention (and action) from the administrator.



SNMP Extension Agent Installation for Linux

You must have administrative level permission to install external RAID adapter software. This procedure assumes that the external

RAID adapter hardware and Linux are installed and operational in your system.

For the SNMP Extension Agent Installation for Linux procedure, please refer to **<CD-ROM>\packages\Linux\SNMP\Readme** or download from **<http://www.areca.com.tw>**

SNMP Extension Agent Installation for FreeBSD

You must have administrative level permission to install external RAID adapter software. This procedure assumes that the external RAID adapter hardware and FreeBSD are installed and operational in your system. For the SNMP Extension Agent Installation for FreeBSD procedure please refer to **<CD-ROM>\packages\FreeBSD\SNMP\Readme** or download from **<http://www.areca.com.tw>**

APPENDIX

Appendix D

Event Notification Configurations

The controller classifies disk array events into four levels depending on their severity. These include level 1: Urgent, level 2: Serious, level 3: Warning and level 4: Information. The level 4 covers notification events such as initialization of the controller and initiation of the rebuilding process; Level 2 covers notification events which once have happen; Level 3 includes events which require the issuance of warning messages; Level 1 is the highest level, and covers events the need immediate attention (and action) from the administrator. The following lists sample events for each level:

A. Device Event

Event	Level	Meaning	Action
Device Inserted	Warning	HDD inserted	
Device Removed	Warning	HDD removed	
Reading Error	Warning	HDD reading error	Keep Watching HDD status, may be it caused by noise or HDD unstable.
Writing Error	Warning	HDD writing error	Keep Watching HDD status, may be it caused by noise or HDD unstable.
ATA Ecc Error	Warning	HDD ECC error	Keep Watching HDD status, may be it caused by noise or HDD unstable.
Change ATA Mode	Warning	HDD change ATA mode	Check HDD connection
Time Out Error	Warning	HDD time out	Keep Watching HDD status, maybe it caused by noise or HDD unstable.
Device Failed	Urgent	HDD failure	Replace HDD
PCI Parity Error	Serious	PCI parity error	If only happen once, it may be caused by noise. If always happen, please check power supply or contact to us.
Device Failed(SMART)	Urgent	HDD SMART failure	Replace HDD

PassThrough Disk Created	Inform	Pass Through Disk created	
PassThrough Disk Modified	Inform	Pass Through Disk modified	
PassThrough Disk Deleted	Inform	Pass Through Disk deleted	

B. Volume Event

Event	Level	Meaning	Action
Start Initialize	Warning	Volume initialization has started	
Start Rebuilding	Warning	Volume rebuilding has started	
Start Migrating	Warning	Volume migration has started	
Start Checking	Warning	Volume parity checking has started	
Complete Init	Warning	Volume initialization completed	
Complete Rebuild	Warning	Volume rebuilding completed	
Complete Migrate	Warning	Volume migration completed	
Complete Check	Warning	Volume parity checking completed	
Create Volume	Warning	New volume created	
Delete Volume	Warning	Volume deleted	
Modify Volume	Warning	Volume modified	
Volume Degraded	Urgent	Volume degraded	Replace HDD
Volume Failed	Urgent	Volume failure	
Failed Volume Revived	Urgent	Failed volume revived	
Abort Initialization	Warning	Initialization been aborted	
Abort Rebuilding	Warning	Rebuilding aborted	
Abort Migration	Warning	Migration aborted	
Abort Checking	Warning	Parity check aborted	
Stop Initialization	Warning	Initialization stopped	
Stop Rebuilding	Warning	Rebuilding stopped	
Stop Migration	Warning	Migration stopped	
Stop Checking	Warning	Parity check stopped	

APPENDIX

C. RAID Set Event

Event	Level	Meaning	Action
Create RaidSet	Warning	New raidset created	
Delete RaidSet	Warning	Raidset deleted	
Expand RaidSet	Warning	Raidset expanded	
Rebuild RaidSet	Warning	Raidset rebuilding	
RaidSet Degraded	Urgent	Raidset degraded	Replace HDD

D. Hardware Monitor Event

Event	Level	Meaning	Action
DRAM 1-Bit ECC	Urgent	DRAM 1-Bit ECC error	Check DRAM
DRAM Fatal Error	Urgent	DRAM fatal error encountered	Check the DRAM module and replace with new one if required.
Controller Over Temperature	Urgent	Abnormally high temperature detected on controller (over 60 degree)	Check air flow and cooling fan of the enclosure, and contact us.
Hdd Over Temperature	Urgent	Abnormally high temperature detected on Hdd (over 55 degree)	Check air flow and cooling fan of the enclosure.
Fan Failed	Urgent	Cooling Fan # failure or speed below 1700RPM	Check cooling fan of the enclosure and replace with a new one if required.
Controller Temp. Recovered	Serious	Controller temperature back to normal level	
Hdd Temp. Recovered			
Raid Power On	Warning	Raid power on	
Test Event	Urgent	Test event	
Power On With Battery Backup	Warning	Raid power on with battery backup	
Incomplete RAID Discovered	Serious	Some RAID set member disks missing before power on	Check disk information to find out which channel missing.
HTTP Log In	Serious	a HTTP login detected	

Telnet Log	Serious	a Telnet login detected	
InVT100 Log In	Serious	a VT100 login detected	
API Log In	Serious	a API login detected	
Lost Rebuilding/ MigrationLBA	Urgent	Some rebuilding/ migration raidset member disks missing before power on.	Reinserted the missing member disk back, controller will continue the incompleted rebuilding/ migration.

Note:

It depends on models, not every model will encounter all events.

APPENDIX

Appendix E


RAID Concept

RAID Set

A RAID set is a group of disks connected to a RAID controller. A RAID set contains one or more volume sets. The RAID set itself does not define the RAID level (0, 1, 10, 3, 5, 6, etc); the RAID level is defined within each volume set. Therefore, volume sets are contained within RAID sets and RAID Level is defined within the volume set. If physical disks of different capacities are grouped together in a RAID set, then the capacity of the smallest disk will become the effective capacity of all the disks in the RAID set.

Volume Set

Each volume set is seen by the host system as a single logical device (in other words, a single large virtual hard disk). A volume set will use a specific RAID level, which will require one or more physical disks (depending on the RAID level used). RAID level refers to the level of performance and data protection of a volume set. The capacity of a volume set can consume all or a portion of the available disk capacity in a RAID set. Multiple volume sets can exist in a RAID set. For the external RAID adapter, a volume set must be created either on an existing RAID set or on a group of available individual disks (Disks that are about to become part of a RAID set). If there are pre-existing RAID sets with available capacity and enough disks for the desired RAID level, then the volume set can be created in the existing RAID set of the user's choice.



In the illustration, volume 1 can be assigned a RAID level 5 of operation while volume 0 might be assigned a RAID level 10 of operation. Alternatively, the free space can be used to create volume 2, which could then be set to use RAID level 5.

Ease of Use Features

• Foreground Availability/Background Initialization

RAID 0 and RAID 1 volume sets can be used immediately after creation because they do not create parity data. However, RAID 3, 5 and 6 volume sets must be initialized to generate parity information. In background Initialization, the initialization proceeds as a background task, and the volume set is fully accessible for system reads and writes. The operating system can instantly access the newly created arrays without requiring a reboot and without waiting for initialization to complete. Furthermore, the volume set is protected against disk failures while initialing. If using Foreground Initialization, the initialization process must be completed before the volume set is ready for system accesses.

• Online Array Roaming

The external RAID adapters store RAID configuration information on the disk drives. The controller therefore protects the configuration settings in the event of controller failure. Array roaming allows the administrators the ability to move a completely RAID set to another system without losing RAID configuration information or data on that RAID set. Therefore, if a server fails, the RAID set disk drives can be moved to another server with an Areca RAID controller and the disks can be inserted in any order.

• Online Capacity Expansion


Online Capacity Expansion makes it possible to add one or more physical drives to a volume set without interrupting server operation, eliminating the need to backup and restore after reconfiguration of the RAID set. When disks are added to a RAID set,

APPENDIX

unused capacity is added to the end of the RAID set. Then, data on the existing volume sets (residing on the newly expanded RAID set) is redistributed evenly across all the disks. A contiguous block of unused capacity is made available on the RAID set. The unused capacity can be used to create additional volume sets.


A disk, to be added to a RAID set, must be in normal mode (not failed), free (not spare, in a RAID set, or passed through to host) and must have at least the same capacity as the smallest disk capacity already in the RAID set.

Capacity expansion is only permitted to proceed if all volumes on the RAID set are in the normal status. During the expansion process, the volume sets being expanded can be accessed by the host system. In addition, the volume sets with RAID level 1, 10, 3, 5 or 6 are protected against data loss in the event of disk failure(s). In the case of disk failure, the volume set changes from "migrating" state to "migrating+degraded" state. When the expansion is completed, the volume set would then change to "degraded" mode. If a global hot spare is present, then it further change to the "rebuilding" state.



The expansion process is illustrated as following figure.

The external RAID adapter redistributes the original volume set over the original and newly added disks, using the same fault-tolerance configuration. The unused capacity on the expand RAID set can then be used to create an additional volume set, with a different fault tolerance setting (if required by the user.)



• Online RAID Level and Stripe Size Migration

For those who wish to later upgrade to any RAID capabilities, a system with Areca online RAID level/stripe size migration allows a simplified upgrade to any supported RAID level without having to reinstall the operating system.

The external RAID adapters can migrate both the RAID level and stripe size of an existing volume set, while the server is online and the volume set is in use. Online RAID level/stripe size migration can prove helpful during performance tuning activities as well as when additional physical disks are added to the external RAID adapter. For example, in a system using two drives in RAID level 1, it is possible to add a single drive and add capacity and retain fault tolerance. (Normally, expanding a RAID level 1 array would require the addition of two disks). A third disk can be added to the existing RAID logical drive and the volume set can then be migrated from RAID level 1 to 5. The result would be parity fault tolerance and double the available capacity without taking the system down. A fourth disk could be added to migrate to RAID level 6. It is only possible to migrate to a higher RAID level by adding a disk; disks in an existing array can't be reconfigured for a higher RAID level without adding a disk.

Online migration is only permitted to begin, if all volumes to be migrated are in the normal mode. During the migration process, the volume sets being migrated are accessed by the host system. In addition, the volume sets with RAID level 1, 10, 3, 5 or 6 are protected against data loss in the event of disk failure(s). In the case of disk failure, the volume set transitions from mi-

APPENDIX

grating state to (migrating+degraded) state. When the migration is completed, the volume set transitions to degraded mode. If a global hot spare is present, then it further transitions to rebuilding state.

• Online Volume Expansion

Performing a volume expansion on the controller is the process of growing only the size of the latest volume. A more flexible option is for the array to concatenate an additional drive into the RAID set and then expand the volumes on the fly. This happens transparently while the volumes are online, but, at the end of the process, the operating system will detect free space at after the existing volume.

Windows, NetWare and other advanced operating systems support volume expansion, which enables you to incorporate the additional free space within the volume into the operating system partition. The operating system partition is extended to incorporate the free space so it can be used by the operating system without creating a new operating system partition.

You can use the Diskpart.exe command line utility, included with Windows Server 2003 or the Windows 2000 Resource Kit, to extend an existing partition into free space in the dynamic disk.

Third-party software vendors have created utilities that can be used to repartition disks without data loss. Most of these utilities work offline. Partition Magic is one such utility.

High availability

• Global Hot Spares

A global hot spare is an unused online available drive, which is ready for replacing the failure disk. The global hot spare is one of the most important features that external RAID adapters provide to deliver a high degree of fault-tolerance. A global hot spare is a spare physical drive that has been marked as a global hot spare and therefore is not a member of any RAID set. If a disk drive

used in a volume set fails, then the global hot spare will automatically take its place and the data previously located on the failed drive is reconstructed on the global hot spare.

For this feature to work properly, the global hot spare must have at least the same capacity as the drive it replaces. Global hot spares only work with RAID level 1, 10, 3, 5, or 6 volume set. You can configure up to three global hot spares with ARC-11xx/12xx.

The “Create Hot Spare” option gives you the ability to define a global hot spare disk drive. To effectively use the global hot spare feature, you must always maintain at least one drive that is marked as a global spare.

Important:

The hot spare must have at least the same capacity as the drive it replaces.

• Hot-Swap Disk Drive Support

The external RAID adapter chip includes a protection circuit that supports the replacement of SATA hard disk drives without having to shut down or reboot the system. A removable hard drive tray can deliver “hot swappable” fault-tolerant RAID solutions at prices much less than the cost of conventional SCSI hard disk RAID adapters. This feature provides advanced fault tolerant RAID protection and “online” drive replacement.

• Auto Declare Hot-Spare

If a disk drive is brought online into a system operating in degraded mode, The external RAID adapters will automatically declare the new disk as a spare and begin rebuilding the degraded volume. The auto declare hot-spare function requires that the smallest drive contained within the volume set in which the failure occurred.

In the normal status, the newly installed drive will be reconfigured an online free disk. But, the newly-installed drive is automatically assigned as a hot spare if any hot spare disk was used to rebuild and without new installed drive replaced it. In this condition, the auto declare hot-spare status will be disappeared if the RAID subsystem has since powered off/on.

APPENDIX

The Hot-Swap function can be used to rebuild disk drives in arrays with data redundancy such as RAID level 1, 10, 3, 5, and 6.

• Auto Rebuilding

If a hot spare is available, the rebuild starts automatically when a drive fails. The external RAID adapters automatically and transparently rebuild failed drives in the background at user-definable rebuild rates.

If a hot spare is not available, the failed disk drive must be replaced with a new disk drive so that the data on the failed drive can be automatically rebuilt and so that fault tolerance can be maintained.

The external RAID adapters will automatically restart the system and the rebuilding process if the system is shut down or powered off abnormally during a reconstruction procedure condition.

When a disk is hot swapped, although the system is functionally operational, the system may no longer be fault tolerant. Fault tolerance will be lost until the removed drive is replaced and the rebuild operation is completed.

During the automatic rebuild process, system activity will continue as normal, however, the system performance and fault tolerance will be affected.

• Adjustable Rebuild Priority

Rebuilding a degraded volume incurs a load on the RAID subsystem. The external RAID adapters allow the user to select the rebuild priority to balance volume access and rebuild tasks appropriately. The "Background Task Priority" is a relative indication of how much time the controller devotes to a background operation, such as rebuilding or migrating.

The external RAID adapter allows user to choose the task priority (Ultra Low (5%), Low (20%), Medium (50%), High (80%)) to balance volume set access and background tasks appropriately. For high array performance, specify an "Ultra Low" value. Like volume

initialization, after a volume rebuilds, it does not require a system reboot.

High Reliability

• Hard Drive Failure Prediction

In an effort to help users avoid data loss, disk manufacturers are now incorporating logic into their drives that acts as an "early warning system" for pending drive problems. This system is called SMART. The disk integrated controller works with multiple sensors to monitor various aspects of the drive's performance, determines from this information if the drive is behaving normally or not, and makes available status information to external RAID adapter firmware that probes the drive and look at it.

The SMART can often predict a problem before failure occurs. The controllers will recognize a SMART error code and notify the administrator of an impending hard drive failure.

• Auto Reassign Sector

Under normal operation, even initially defect-free drive media can develop defects. This is a common phenomenon. The bit density and rotational speed of disks is increasing every year, and so are the potential of problems. Usually a drive can internally remap bad sectors without external help using cyclic redundancy check (CRC) checksums stored at the end of each sector.

SATA drives perform automatic defect re-assignment for both read and write errors. Writes are always completed - if a location to be written is found to be defective, the drive will automatically relocate that write command to a new location and map out the defective location. If there is a recoverable read error, the correct data will be transferred to the host and that location will be tested by the drive to be certain the location is not defective. If it is found to have a defect, data will be automatically relocated, and the defective location is mapped out to prevent future write attempts.

In the event of an unrecoverable read error, the error will be reported to the host and the location will be flagged as being po-

APPENDIX

tentially defective. A subsequent write to that location will initiate a sector test and relocation should that location prove to have a defect. Auto Reassign Sector does not affect disk subsystem performance because it runs as a background task. Auto Reassign Sector discontinues when the operating system makes a request.

• Consistency Check

A consistency check is a process that verifies the integrity of redundant data. To verify RAID 3, 5 or 6 redundancy, a consistency check reads all associated data blocks, computes parity, reads parity, and verifies that the computed parity matches the read parity.

Consistency checks are very important because they detect and correct parity errors or bad disk blocks in the drive. A consistency check forces every block on a volume to be read, and any bad blocks are marked; those blocks are not used again. This is critical and important because a bad disk block can prevent a disk rebuild from completing. We strongly recommend that you run consistency checks on a regular basis—at least once per week. Note that consistency checks degrade performance, so you should run them when the system load can tolerate it.

Data Protection

• Battery Backup

The external RAID adapters are armed with a Battery Backup Module (BBM). While a Uninterruptible Power Supply (UPS) protects most servers from power fluctuations or failures, a BBM provides an additional level of protection. In the event of a power failure, a BBM supplies power to retain data in the RAID controller's cache, thereby permitting any potentially dirty data in the cache to be flushed out to secondary storage when power is restored.

The batteries in the BBM are recharged continuously through a trickle-charging process whenever the system power is on. The batteries protect data in a failed server for up to three or four

days, depending on the size of the memory module. Under normal operating conditions, the batteries last for three years before replacement is necessary.

• **Recovery ROM**

The external RAID adapter firmware is stored on the flash ROM and is executed by the I/O processor. The firmware can also be updated through the PCI-X/PCIe bus port or Ethernet port (if equipped) without the need to replace any hardware chips. During the controller firmware upgrade flash process, it is possible for a problem to occur resulting in corruption of the adapter firmware. With our Redundant Flash Image feature, the adapter will revert back to the last known version of firmware and continue operating. This reduces the risk of system failure due to firmware crash.

Appendix F

Understanding RAID


RAID is an acronym for Redundant Array of Independent Disks. It is an array of multiple independent hard disk drives that provides high performance and fault tolerance. The external RAID adapter implements several levels of the Berkeley RAID technology. An appropriate RAID level is selected when the volume sets are defined or created. This decision should be based on the desired disk capacity, data availability (fault tolerance or redundancy), and disk performance. The following section discusses the RAID levels supported by the external RAID adapter.

The external RAID adapter makes the RAID implementation and the disks' physical configuration transparent to the host operating system. This means that the host operating system drivers and software utilities are not affected, regardless of the RAID level selected. Correct installation of the disk array and the controller requires a proper understanding of RAID technology and the concepts.

APPENDIX


• RAID 0

RAID 0, also referred to as striping, writes stripes of data across multiple disk drives instead of just one disk drive. RAID 0 does not provide any data redundancy, but does offer the best high-speed data throughput. RAID 0 breaks up data into smaller blocks and then writes a block to each drive in the array. Disk striping enhances performance because multiple drives are accessed simultaneously; the reliability of RAID level 0 is less because the entire array will fail if any one disk drive fails.




• RAID 1

RAID 1 is also known as “disk mirroring”; data written on one disk drive is simultaneously written to another disk drive. Read performance will be enhanced if the array controller can, in parallel, access both members of a mirrored pair. During writes, there will be a minor performance penalty when compared to writing to a single disk. If one drive fails, all data (and software applications) are preserved on the other drive. RAID 1 offers extremely high data reliability, but at the cost of doubling the required data storage capacity.




• RAID 10

RAID 10 is a combination of RAID 0 and RAID 1, combining striping with disk mirroring. RAID Level 10 combines the fast performance of Level 0 with the data redundancy of Level 1. In this configuration, data is distributed across several disk drives, similar to Level 0, which are then duplicated to another set of drive for data protection. RAID 10 has been traditionally implemented using an even number of disks, some hybrids can use an odd number of disks as well. Illustration is an example of a hybrid RAID 10 array comprised of five disks; A, B, C, D and E. In this configuration, each stripe is mirrored on an adjacent disk with wrap-around. Areca RAID 10 offers a little more flexibility in choosing the number of disks that can be used to constitute an array. The number can be even or odd.




• RAID 3

RAID 3 provides disk striping and complete data redundancy through a dedicated parity drive. RAID 3 breaks up data into smaller blocks, calculates parity by performing an exclusive-or on the blocks, and then writes the blocks to all but one drive in the array. The parity data created during the exclusive-or is then written to the last drive in the array. If a single drive fails, data is still available by computing the exclusive-or of the contents corresponding stripes of the surviving member disk. RAID 3 is best for applications that require very fast data-transfer rates or long data blocks.




• RAID 5

RAID 5 is sometimes called striping with parity at byte level. In RAID 5, the parity information is written to all of the drives in the controllers rather than being concentrated on a dedicated parity disk. If one drive in the system fails, the parity information can be used to reconstruct the data from that drive. All drives in the array system can be used for seek operations at the same time, greatly increasing the performance of the RAID system. This relieves the write bottleneck that characterizes RAID 4, and is the primary reason that RAID 5 is more often implemented in RAID arrays.



• RAID 6

RAID 6 provides the highest reliability. It is similar to RAID 5, but it performs two different parity computations or the same computation on overlapping subsets of the data. RAID 6 can offer fault tolerance greater than RAID 1 or RAID 5 but only consumes the capacity of 2 disk drives for distributed parity data. RAID 6 is an extension of RAID 5 but uses a second, independent distributed parity scheme. Data is striped on a block level across a set of drives, and then a second set of parity is calculated and written across all of the drives.



• JBOD

(Just a Bunch Of Disks) A group of hard disks in a RAID controller are not set up as any type of RAID configuration. All drives are available to the operating system as an individual disk. JBOD does not provide data redundancy.

• Single Disk (Pass Through Disk)

Pass through disk refers to a drive that is not controlled by the RAID firmware and thus can not be a part of a RAID volume. The drive is available to the operating system as an individual disk.

APPENDIX

Summary of RAID Levels

The external RAID adapter supports RAID Level 0, 1, 10, 3, 5 and 6. The table below provides a summary of RAID levels.

Features and Performance					
RAID Level	Description	Min. Drives	Data Reliability	Data Transfer Rate	I/O Request Rates
0	Also known as striping Data distributed across multiple drives in the array. There is no data protection.	1	No data Protection	Very High	Very High for Both Reads and Writes
1	Also known as mirroring All data replicated on N separated disks. N is almost always 2. This is a high availability solution, but due to the 100% duplication, it is also a costly solution. Half of drive capacity in array devoted to mirroring.	2	Lower than RAID 6; Higher than RAID 3, 5	Writes similar to a single disk	Reads are twice as fast as a single disk; Write are similar to a single disk.
10	Also known Block-Interleaved Parity. Data and parity information is subdivided and distributed across all disks. Parity must be the equal to the smallest disk capacity in the array. Parity information normally stored on a dedicated parity disk.	3	Lower than RAID 6; Higher than RAID 3, 5	Transfer rates more similar to RAID 1 than RAID 0	Reads are twice as fast as a single disk; Writes are similar to a single disk.
3	Also known Bit-Interleaved Parity. Data and parity information is subdivided and distributed across all disks. Parity data consumes the capacity of 1 disk drive. Parity information normally stored on a dedicated parity disk.	3	Lower than RAID 1, 10, 6; Higher than a single drive	Reads are similar to RAID 0; Writes are slower than a single disk	Reads are close to being twice as fast as a single disk; Writes are similar to a single disk.

5	Also known Block-Interleaved Distributed Parity. Data and parity information is subdivided and distributed across all disk. Parity data consumes the capacity of 2 disk drive.	3	Lower than RAID 1, 10, 6; Higher than a single drive	Reads are similar to RAID 0; Writes are slower than a single disk	Reads are similar to RAID 0; Writes are slower than a single disk.
6	RAID 6 provides the highest reliability. Similar to RAID 5, but does two different parity computations. RAID 6 offers fault tolerance greater than RAID 1 or RAID 5. Parity data consumes the capacity of 2 disk drives.	4	Highest reliability	Reads are similar to RAID 0; Writes are slower than a single disk	Reads are similar to RAID 0; Writes are slower than a single disk.

APPENDIX

Appendix H

Technical Support

Areca Technical Support provides several options for Areca users to access information and updates. We encourage you to use one of our electric services, for the latest product information updates and efficient support service. If you have decided to contact us, please have the following information ready. Kindly provide us the product model, serial number, BIOS, driver version, and a detailed description of the problem at **http://www.areca.com.tw/support/ask_a_question.htm** Our support team will be glad to answer all your technical enquires.