

External Disk Tower

ARC-4036MI

(With 4/8-port Direct Attached 6Gb/s SAS/SATA
Disk Box)

Quick Installation Guide

Version: 1.1

Issue Date: February, 2015

Copyright and Trademarks

The information of the products in this manual is subject to change without prior notice and does not represent a commitment on the part of the vendor, who assumes no liability or responsibility for any errors that may appear in this manual. All brands and trademarks are the properties of their respective owners. This manual contains materials protected under International Copyright Conventions. All rights reserved. No part of this manual may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without the written permission of the manufacturer and the author.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Manufacturer's Declaration for CE Certification

We confirm ARC-4036MI has been tested and found compliant with the requirements in the council directive relating to the EMC Directive 2004/108/EC. Regarding to the electromagnetic compatibility, the following standards were applied:

EN 55022: 2006, Class B
EN 61000-3-2: 2006
EN 61000-3-3: 1995+A1: 2001+A2: 2005

EN 55024:1998+A1:2001=A2:2003
IEC61000-4-2: 2001
IEC61000-4-3: 2006
IEC61000-4-4: 2004
IEC61000-4-5: 2005
IEC61000-4-6: 2006
IEC61000-4-8: 2001
IEC61000-4-11: 2004

Contents

1. Introduction	4
1.1 Overview	4
1.2 Features	4
2. Hardware Installation	6
2.1 Before You First Installing.....	6
2.1 Drive Box Interconnects.....	7
2.3 RAID adapter Board Layout	8
2.4 Installation.....	9

Quick Installation Guide

1. Introduction

This manual presents brief example of Areca compact disk tower box with external PCIe RAID adapters.

1.1 Overview

The ARC-4036MI disk tower is an external solution with SFF-8088 host connectivity for use with your PC and Mac. With ARC-4036MI drive box, it can support up to 8 disks tower box. The ARC-4036MI is for hots or RAID adapter with 2 external SFF-8088 connectors which support up to 8 direct attached SAS/SATA signals. Designed and leveraged with Areca existing high performance external PCIe RAID adapter, this solution delivers high-capacity performance at the best of cost/performance value. The intelligent cooling continuously adapts to environmental conditions by automatically controlling the speed of cooling fans. This super silent design, optimizing balance between noise reduction and necessary cooling, helps the resellers to offer the cost effective storage solution to the end customers.

ARC-4036MI has integrated the 6Gb/s re-driver chip on its backplane. This can guarantee the signal from external connector on the external 6Gb/s SAS RAID adapter to the ARC-4036MI backplane connector.

The ARC-1215-4x and ARC-1225-8x with ARC-4036MI deliver superior overall performance compared to others external PCIe solution. High transfer rates make the ARC-1215-4x and ARC-1225-8x with ARC-4036MI well suited for audio/video application especially the rapidly growing demand from the Mac video editing markets.

1.2 Features

Disk Tower Features

- Cable-free 6Gb/s re-driver SAS/SATA backplane design for 8 removable drive trays
- Simple serial bus connection for fault/activity LED (only with Areca external RAID adapter)
- Compatible with SAS host bus adapter and SAS RAID controllers

Quick Installation Guide

- Built-in intelligent cooling fans for self-contained ventilation and buzzer alarm

External Compact Disk Tower Box	
	ARC-4036MI
Host Connector	2 x SFF-8088
Host Type Cable	1 or 2 x SFF-8088 to SFF-8088
Disk Interface	8 x 6Gb/s SAS/SATA
Form Factor	Compact – 8 Disks Tower
Power Supply/In/Out	220W / 90-265V AC/ +12V/16A, +5V/16A, +3.3V/14A
Dimension (W x H x D)	146 x 302 x 290 mm
Weight	14.9 lbs / 6.8Kg

PCIe 3.0 External 6Gb/s SAS RAID Adapter Comparison		
Model name	ARC-1215-4x	ARC-1225-8x
I/O Processor	Dual Core RAID-on-Chip (ROC) 800 MHz Processor	
Form Factor	Low Profile: 64.4(H) x 169.5(L) mm	
Host Bus Type	PCIe 3.0 x 8 Lanes	
Driver Connector	1 x SFF-8088	2 x SFF-8088
Drive Support	4 x SAS/SATA	8 x SAS/SATA
RAID Level	0, 1, 10, 3, 5, 6, Single Disk or JBOD	0, 1, 10, 3, 5, 6, 30, 50, 60, Single Disk or JBOD
On-Board Cache	1GB on-board DDR3-1333 SDRAM with ECC	
Management Port	In-Band: PCIe Out-of-Band: BIOS and LCD (option)	
Enclosure Ready	External Serial Bus	

Quick Installation Guide

2. Hardware Installation

This section describes the procedures for installing Areca 8 bays disk tower.

2.1 Before You First Installing

Thanks for purchasing the Areca 8 bays disk tower as your data storage subsystem. This quick installation guide gives simple step-by-step instructions for installing and configuring the Areca 8 bays disk tower. To ensure personal safety and to protect your equipment and data, reading the following information package list carefully before you begin installing.

Package Contents

Open the package carefully, and make sure that none of the items listed below are missing. **(disk drives and disk mounting brackets are not included):**


ARC-4036MI

- ARC-4036MI 8 disk Mini SAS 4x (MS) disk tower
- 2 x external SFF-8088 to SFF-8088 cable (optional)
- 1 x serial communications RJ11 to RS-232C cable
- 32 x drive mounting screws (4 screws for each tray)
- 1 x Quick Installation Guide

Quick Installation Guide

2.1 Drive Box Interconnects

The following figures illustrate the ARC-4036MI disk tower connector location and definitions.



Front View	Rear View
<ul style="list-style-type: none">1. Disk Activity LED2. Disk Fault/Link LED	<ul style="list-style-type: none">3. System Fan4. Power Connector5. RJ11 (SI) Serial Bus Input6. Power Supply Fan7. Min SAS (MS) Connector08. Min SAS (MS) Connector19. On/Off Switch

Quick Installation Guide

2.3 RAID adapter Board Layout

The following figures illustrate the Areca external PCIe 3.0 6Gb/s SAS/SATA RAID adapter connector location and definitions. If you need more detailed information about external RAID adapter, please visit: <http://www.areca.com.tw>




Figure 2-1, ARC-1215-4x/ARC-1225-8x (PCIe 3.0 x8 external 6Gb/s SAS RAID controller)

Connector	Type	Description
1. (J1)	Battery Backup Module Connector	12-pin box header
2. (J2)	Manufacture Purpose Port	10-pin header
3. (J5)	I ² C/LCD Connector	RS232 Male Connector
4. (SCN1)	SAS 1-4 Ports (External)	SFF-8088
5. (SCN2)	SAS 5-8 Ports (External)	SFF-8088

Table 2-1, ARC-1215-4x/ARC-1225-8x connectors

2.4 Installation

Your enclosure supports up to 8 3.5-inch disk drives or 2.5-inch SAS or SATA 6.0Gb/s drives, each one contained in its individual drive carrier. Each drive is hot-pluggable, allowing you to remove and insert drives without shutting down your enclosure.

Following the instruction below to install ARC-4036MI compact tower enclosure.

Step 1. Installing SAS/SATA Drives in the ARC-4036MI Enclosure

Follow the steps below to install the 3.5-inch drives or 2.5-inch drives into the drive tray.

- a. Install the drives into the drive tray and make sure the holes of the disk trays align with the holes of the drive.




Figure 2-2, Put 2.5-inch SAS/SATA drive into disk tray




Figure 2-3, Put 3.5-inch SAS/SATA drive into disk tray

- b. Turn the drive tray upside down and using a screwdriver to secure the drive to the drive tray by four of the mounting screws.



Figure 2-4, Drive carrier with 2.5-inch SAS/SATA drive



Figure 2-5, Drive carrier with 3.5-inch SAS/SATA drive

Quick Installation Guide

- c. After all drives are in the drive tray, slide all of them back into the ARC-4036MI enclosure and make sure you latch the drive trays.




Figure 2-6, Slide drive tray back into the ARC-4036MI

Note:

Please secure four of the mounting screws to the tray, otherwise the ARC-4036MI may produce an annoying BUZZ sound in a few environments.

Step 2. Connect the External Box Cable

The ARC-4036MI is an external solution with Mini SAS SFF-8088 host connectivity for use with your PC or Mac workstation.






Figure 2-7, Mini SAS 4x to Mini SAS 4x Cable

Quick Installation Guide




Step 3. Install the External Serial Bus LED Cable (Optional)

You also can connect the serial bus interface RJ11 connector to Areca external RAID adapter RS232 connector. This signal provide the drive status information including activity LED and fault LED.

The following is the serial bus signal name description for LCD & fault/activity LED on the Areca RAID adapter.

Quick Installation Guide



PIN	Description	PIN	Description
		1	GND
6	LCD Module Serial Data	2	Power (+5V)
7	LCD Module Clock	3	N/C
8	Fault/Activity Serial Data (ACS)	4	LCD Module Interrupt
9	N/C	5	Fault/Activity CLK (ACS)

You can connect the serial bus from the ARC-4036MI serial bus input connector (RJ11) to the Areca RAID adapter serial bus output connector (RS-232), as shown below.




Figure 2-8, Connector Connected Between Areca External RAID Adapter ARC-1225-8x & ARC-4036MI

Quick Installation Guide

The following table describes the fault/activity LED function.




Figure 2-9, Activity/Fault LED for External ARC-4036MI.

Tray LED	Normal Status	Problem Indication
1. Activity LED (Blue)	<ol style="list-style-type: none">1. When the activity LED is lit, there is I/O activity on that disk drive.2. When the LED is not lit; there is no activity on that disk drive.	N/A
2. Fault/Link LED (Red/Green)	<ol style="list-style-type: none">1. When the fault LED is lit, there is no disk present.2. When the link LED is lit, there is a disk present.	<ol style="list-style-type: none">1. When the fault LED is off, the disk is present and status is normal.2. When the fault LED is blinking (2 times/sec.), the disk drive has failed and should be hot-swapped immediately.3. When the activity LED is lit and fault LED is fast blinking (10 times/sec.) there is rebuilding activity on that disk drive.